




**Count on it.**

Form No. 3401-570 Rev C

# Operator's Manual

## LT-F3000 Heavy-Duty Triple Turf Flail Mower

Model No. 30659—Serial No. 316000001 and Up



G034620



This product complies with all relevant European directives. For details, please see the separate product specific Declaration of Conformity (DOC) sheet.

# Introduction

This machine is a ride-on lawn mower intended to be used by professional, hired operators in commercial applications. It is primarily designed for cutting grass on parks, sports fields, caravan parks, cemeteries, and commercial grounds. It is designed for cutting long and short grass.

Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

Visit [www.Toro.com](http://www.Toro.com) for more information, including safety tips, training materials, accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Dealer or Toro Customer Service and have the model and serial numbers of your product ready. [Figure 1](#) identifies the location of the model and serial numbers on the product. Write the numbers in the space provided.




Figure 1

1. Location of the model and serial numbers

|                  |
|------------------|
| Model No. _____  |
| Serial No. _____ |

This manual identifies potential hazards and has safety messages identified by the safety alert symbol ([Figure 2](#)), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



Figure 2  
Safety-alert symbol

This manual uses 2 words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

# Contents

|                                                                |    |
|----------------------------------------------------------------|----|
| Safety .....                                                   | 4  |
| General Safety .....                                           | 4  |
| Safety and Instructional Decals .....                          | 4  |
| Setup .....                                                    | 10 |
| Product Overview .....                                         | 10 |
| Controls .....                                                 | 11 |
| Specifications .....                                           | 19 |
| Attachments/Accessories .....                                  | 19 |
| Before Operation .....                                         | 20 |
| Before Operation Safety .....                                  | 20 |
| Performing Daily Maintenance .....                             | 20 |
| Filling the Fuel Tank .....                                    | 20 |
| During Operation .....                                         | 21 |
| During Operation Safety .....                                  | 21 |
| Using the Operator Platform Latching Mechanism .....           | 22 |
| Understanding the Operator Presence Controls .....             | 22 |
| Folding the Roll Bar .....                                     | 23 |
| Checking the Interlock Switches .....                          | 24 |
| Starting the Engine .....                                      | 24 |
| Shutting Off the Engine .....                                  | 25 |
| Flail Cutting Unit General Information .....                   | 25 |
| Adjusting the Height of Cut .....                              | 25 |
| Controlling the Position of the Individual Cutting Units ..... | 26 |
| Using the Cutting Unit Auto-Limited Lift in Reverse .....      | 26 |
| Engaging the Cutting Unit Drive .....                          | 27 |
| Using Weight-Transfer/Traction Assistance .....                | 27 |
| Operating Tips .....                                           | 28 |
| After Operation .....                                          | 28 |
| After Operation Safety .....                                   | 28 |
| Identifying the Tie-Down Points .....                          | 29 |
| Hauling the Machine .....                                      | 29 |
| Locating the Jacking Points .....                              | 29 |
| Towing the Machine .....                                       | 29 |
| Maintenance .....                                              | 32 |
| Maintenance Safety .....                                       | 32 |
| Recommended Maintenance Schedule(s) .....                      | 33 |
| Daily Maintenance Checklist .....                              | 35 |
| Lubrication .....                                              | 36 |
| Greasing the Bearings, Bushings, and Pivots .....              | 36 |
| Engine Maintenance .....                                       | 36 |
| Engine Safety .....                                            | 36 |
| Checking the Engine Overheat Warning System .....              | 36 |
| Servicing the Air Cleaner .....                                | 37 |
| Checking the Engine-Oil Level .....                            | 38 |
| Servicing the Engine Oil and Filter .....                      | 38 |
| Fuel System Maintenance .....                                  | 39 |
| Draining the Fuel Tank .....                                   | 39 |
| Checking the Fuel Lines and Connections .....                  | 39 |

|                                                                         |    |
|-------------------------------------------------------------------------|----|
| Bleeding the Fuel System .....                                          | 39 |
| Replacing the Fuel Filter .....                                         | 40 |
| Electrical System Maintenance .....                                     | 41 |
| Electrical System Safety .....                                          | 41 |
| Checking the Electrical System .....                                    | 41 |
| Checking the Battery Condition .....                                    | 41 |
| Servicing the Battery .....                                             | 41 |
| Drive System Maintenance .....                                          | 42 |
| Checking the Tire Pressure .....                                        | 42 |
| Checking the Torque of the Wheel-Lug Nuts .....                         | 42 |
| Changing the Transmission Oil Filter .....                              | 42 |
| Changing the Hydraulic-Return Filter .....                              | 42 |
| Checking the Rear-Wheel Alignment .....                                 | 43 |
| Inspecting the Transmission Control Cable and Operating Mechanism ..... | 43 |
| Cooling System Maintenance .....                                        | 44 |
| Cooling System Safety .....                                             | 44 |
| Removing Debris from the Cooling System .....                           | 44 |
| Belt Maintenance .....                                                  | 45 |
| Tensioning the Alternator Belt .....                                    | 45 |
| Controls System Maintenance .....                                       | 46 |
| Checking the Forward/Reverse Travel Pedal Action .....                  | 46 |
| Checking the Operator-Presence-Seat Switch .....                        | 46 |
| Checking the Cutter-Drive-Interlock Switch .....                        | 46 |
| Checking the Parking-Brake-Interlock Switch .....                       | 46 |
| Checking the Transmission-Neutral-Interlock Switch .....                | 46 |
| Hydraulic System Maintenance .....                                      | 47 |
| Hydraulic System Safety .....                                           | 47 |
| Checking the Hydraulic Lines and Hoses .....                            | 47 |
| Checking the Hydraulic Fluid .....                                      | 47 |
| Servicing the Hydraulic System .....                                    | 48 |
| Checking the Hydraulic-Fluid-Overheat Warning System .....              | 48 |
| Cutting Unit Maintenance .....                                          | 49 |
| Blade Safety .....                                                      | 49 |
| Replacing the Blades .....                                              | 49 |
| Checking the Blade Bolts .....                                          | 49 |
| Inspecting the Blades .....                                             | 49 |
| Checking the Rear Guard .....                                           | 50 |
| Clearing a Blocked Rotor .....                                          | 50 |
| Checking the Rubber Guard .....                                         | 51 |
| Checking the Cutting Unit Pivot .....                                   | 51 |
| Checking the Rotor .....                                                | 51 |
| Checking the Rear-Roller Bearing Adjustment .....                       | 51 |
| Checking the Rear-Roller Scraper Wire Tension .....                     | 52 |
| Cleaning .....                                                          | 52 |
| Washing the Machine .....                                               | 52 |
| Storage .....                                                           | 53 |

|                                   |    |
|-----------------------------------|----|
| Storage Safety .....              | 53 |
| Preparing the Traction Unit ..... | 53 |
| Preparing the Engine .....        | 53 |
| Troubleshooting .....             | 54 |

# Safety

This machine has been designed in accordance with EN ISO 5395.

## General Safety

This product is capable of amputating hands and feet and of throwing objects.

- Read and understand the contents of this *Operator's Manual* before starting the engine.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Do not put your hands or feet near moving components of the machine.
- Do not operate the machine without all guards and other safety protective devices in place and functioning properly on the machine.
- Keep bystanders and children out of the operating area. Never allow children to operate the machine.
- Shut off the engine, remove the key, and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.

Improperly using or maintaining this machine can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety-alert symbol , which means Caution, Warning, or Danger—personal safety instruction. Failure to comply with these instructions may result in personal injury or death.

## Safety and Instructional Decals




Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.



40-13-010

decal40-13-010




70-13-072

decal70-13-072

1. Cutting hazard of hand
2. Cutting hazard of foot

1. Jacking point



**70-13-077**

decal70-13-077


1. Warning—shut off the engine and remove the ignition key before releasing or operating safety latches.



**950889**

decal950889


1. Warning—hot surfaces.



**111-0773**

decal111-0773


1. Warning—crushing of fingers, force applied from side.



**111-3277**

decal111-3277

- |                              |                 |
|------------------------------|-----------------|
| 1. Horn                      | 5. Fast         |
| 2. Cutting units—lower/float | 6. Engine speed |
| 3. Cutting units—hold        | 7. Slow         |
| 4. Cutting units—raise       |                 |



**111-3344**

decal111-3344


1. Ignition switch



**111-3562**

decal111-3562


1. Press the pedal to adjust the steering wheel angle.



**111-3566**

decal111-3566


1. Falling, crushing hazard—ensure that the operator-platform latch is engaged before operating.



**111-3567**

decal111-3567


1. Pedal operation



**111-3658**

decal111-3658

1. Cutterhead
2. Latch
3. Unlatch



**111-3901**

decal111-3901


1. Transmission fluid—read the *Operator's Manual*.



**111-3902**


decal111-3902

1. Your hand can be cut by the fan; warning
2. Hot surfaces; read the *Operator's Manual*.



**111-9382**

1. Height-of-cut chart



**111-9647**

1. Read the *Operator's Manual*—fill to the maximum level; do not overfill.




**111-9648**

1. Warning—read the *Operator's Manual*; torque the nuts to 45 N·m (33 ft-lb).



**117-3276**

1. Engine coolant under pressure
2. Explosion hazard—read the *Operator's Manual*.
3. Warning—do not touch the hot surface.
4. Warning—read the *Operator's Manual*.



decal111-5007

## 111-5007

**Note:** This machine complies with the industry standard stability test in the static lateral and longitudinal tests with the maximum recommended slope indicated on the decal. Review the instructions for operating the machine on slopes in the *Operator's Manual* as well as the conditions in which you would operate the machine to determine whether you can operate the machine in the conditions on that day and at that site. Changes in the terrain can result in a change in slope operation for the machine. If possible, keep the cutting units lowered to the ground while operating the machine on slopes. Raising the cutting units while operating on slopes can cause the machine to become unstable.

1. Tipping hazard—drive slowly when turning or going up slopes.
2. Tipping hazard—only drive up slopes that are between 0 and 20°; do not drive up slopes that are greater than 20°.
3. Tipping hazard—wear a seatbelt when the rollbar is up; do not wear a seatbelt when the rollbar is down.
4. Warning—read the *Operator's Manual*; wear hearing protection; remove the key before performing any maintenance.
5. Thrown object hazard—keep bystanders away.

**SPECIFICATIONS/CHANGE INTERVALS**

| SEE OPERATOR'S MANUAL FOR INITIAL CHANGES | FLUID TYPE                                           | CAPACITY   | CHANGE INTERVAL           |                                    | FILTER PART NO   |
|-------------------------------------------|------------------------------------------------------|------------|---------------------------|------------------------------------|------------------|
|                                           |                                                      |            | FLUID                     | FILTER                             |                  |
| ENGINE OIL                                | 10W-30<br>121-5393                                   | 6.7 LITRES | 150 HOURS                 | 150 HOURS                          | 108-3841         |
| HYDRAULIC FLUID                           | ISO VG 46<br>108-1178                                | 32 LITRES  | 500 HOURS                 | 500 HOURS                          | 924692<br>924709 |
| PRIMARY AIR FILTER                        |                                                      |            |                           | 500 HOURS<br>SEE SERVICE INDICATOR | 111-5015         |
| SAFETY AIR FILTER                         |                                                      |            |                           | SEE OPERATOR'S MANUAL              | 111-5016         |
| FUEL SYSTEM                               | > -7 ° C<br>NO. 2 DIESEL<br>< -7 ° C<br>NO. 1 DIESEL | 45 LITRES  |                           | 400 HOURS/<br>YEARLY               | 110-9049         |
| ENGINE COOLANT                            | 50% WATER<br>50% ETHYL GLYCOL                        | 9.5 LITRES | DRAIN & FLUSH EVERY 2 YRS |                                    |                  |

111-9649-A

decal111-9649

## 111-9649

1. Read the *Operator's Manual* for more information on service and maintenance.
2. Tire pressure—1 bar (14.5 psi)
3. Check all fasteners.
4. Check for hydraulic leaks.
5. Check the transmission-oil level.
6. Check the fuel level.
7. Check the oil level.
8. Ensure the blades stop when you leave the operating position.
9. Check the air filter.
10. Inspect the blades for wear.
11. Ensure the bottle is filled to the low line.
12. Clean the cooling system.
13. Clean the machine and torque the front wheel to 200 N·m and the rear wheel to 54 N·m.


# Setup

## Media and Additional Parts

| Description               | Qty. | Use                                                                    |
|---------------------------|------|------------------------------------------------------------------------|
| Operator's Manual         | 1    | Read the manuals before operating the machine.                         |
| Engine owner's manual     | 1    |                                                                        |
| Declaration of Conformity | 1    | The Declaration of Conformity serves as confirmation of CE compliance. |

**Note:** Determine the left and right sides of the machine from the normal operating position.

## Product Overview




**Figure 3**

- |                        |                      |
|------------------------|----------------------|
| 1. Front cutting units | 4. Operator's seat   |
| 2. Control arm         | 5. Engine hood       |
| 3. Steering wheel      | 6. Rear cutting unit |


# Controls

## Control Panel Components




**Figure 4**

- |                                                 |                                                             |
|-------------------------------------------------|-------------------------------------------------------------|
| 1. Ignition switch                              | 11. Transmission-neutral indicator                          |
| 2. Lighting switch (supplied with lighting kit) | 12. Parking-brake switch                                    |
| 3. Limited-lift-in-reverse switch               | 13. Engine-preheat-indicator light                          |
| 4. Throttle-control lever                       | 14. Direction-indicator switch (supplied with lighting kit) |
| 5. Horn button                                  | 15. Differential-lock switch                                |
| 6. Engine-oil-warning light                     | 16. Lift-control switches                                   |
| 7. Battery-charge-warning light                 | 17. Hazard-warning switch (supplied with lighting kit)      |
| 8. Hydraulic-fluid-warning light                | 18. Warning-beacon switch (supplied with beacon kit)        |
| 9. Engine-coolant-warning light                 | 19. Hour meter                                              |
| 10. Cutting-unit-drive switch                   | 20. Auxiliary 12 V socket                                   |



**Figure 5**

1. Weight transfer control



**Figure 6**

1. Reverse travel pedal      2. Forward travel pedal

## Braking System

### Parking Brake

Move the parking-brake switch to the forward position by pressing the smaller locking button and moving the switch forward to engage the parking brake ([Figure 7](#)).

**Note:** Do not operate the mower with the parking brake engaged and do not engage the parking brake while the mower is moving.

This light illuminates when the parking brake is engaged and the ignition key is turned to position I.

## ⚠ WARNING

The parking brake operates on the front wheels only.

Do not park the machine on a slope.




Figure 7

1. Parking-brake switch

### Service Brake

Service braking is achieved by the hydraulic transmission system. When the forward or reverse travel pedals are released or the engine speed is reduced, service braking becomes effective and travel speed is automatically reduced. To increase the braking effect, push the transmission pedal into the NEUTRAL position. Service braking is effective on the front wheels only.

## ⚠ DANGER

The service braking system does not hold the mower at a standstill.

Always ensure that the parking brake is engaged to park the mower at a standstill.

### Emergency Brake

In the event of service brake failure, turn the ignition off to bring the mower to a standstill.

## Throttle Control

Operate the throttle control in a forward direction to increase the engine speed. Operate the throttle control in a rearward direction to reduce engine speed (Figure 8).

**Note:** The engine speed dictates the speed of the other functions, i.e., travel, flail-rotor rotation speed, and cutting unit lift speed.





Figure 8

1. Throttle-control lever

## Travel

**Forward travel:** Press the forward travel pedal to increase forward travel speed. Release the pedal to reduce speed (Figure 9).

**Reverse travel:** Press the reverse travel pedal to increase reverse travel speed. Release the pedal to reduce speed (Figure 9).

**Stop (Neutral):** To stop the machine, use 1 of the following procedures:

- Reduce your foot pressure on the traction pedal and allow it to return to the neutral position. The machine dynamically brakes to a smooth stop.
- Tap or hold the reverse pedal briefly. This stops the machine faster than dynamic braking.




Figure 9

1. Reverse travel pedal      2. Forward travel pedal

## Differential Lock

### ⚠ WARNING

The turning radius increases when the differential lock is engaged. Using the differential lock at high speed may lead to loss of control and cause serious injury and/or property damage.

**Do not use the differential lock at high speed.**

Use the differential lock to prevent excessive wheel spin when the drive wheels lose traction. The differential lock operates in both forward and reverse. You can lock the differential while the machine is traveling slowly. Engine power demand increases when the differential is locked. Prevent excessive power requirements by using the differential lock only at low speed.

To lock the differential, press the differential-lock switch.


To unlock the differential, release the differential-lock switch.

## Cutting-Units Position Controls

Use the cutting-units position controls to independently raise and lower the cutting units; refer to [Controlling the Position of the Individual Cutting Units \(page 26\)](#).

## Transport Latches

Always raise the cutting units to the TRANSPORT position and secure with the transport latches and safety locks when travelling between work areas ([Figure 10](#)).



G014548

g014548

Figure 10

## Cutting-Unit-Drive Switch

To engage the cutting unit drive, refer to [Engaging the Cutting Unit Drive \(page 27\)](#).

**Note:** Always put the cutting-unit-drive switch in the OFF position when travelling between work areas.

## Adjustable Steering Column

Adjustment of the steering wheel and steering column should only be carried out when the mower is at a standstill with the parking brake engaged.

1. To tilt the steering wheel, press the foot pedal down.
2. Position the steering tower to the most comfortable position and release the pedal ([Figure 11](#)).



G014549

g014549

Figure 11

## Operator Seat

### **⚠ WARNING**

Ensure that the operator-platform latch is engaged before operating the machine.

- **Forward/Backward Adjustment:** Move the lever upward to adjust the forward/backward position of the seat. Release the lever to lock the seat in position (Figure 12).




Figure 12

1. Lever

- **Operator weight adjustment:** Rotate the handle clockwise to increase suspension stiffness and counterclockwise to decrease the stiffness. The dial indicates when the optimum suspension adjustment has been set according to operator weight (kg); refer to Figure 13.





Figure 13

1. Lever


2. Dial

- **Height adjustment:** Manually lift the seat for incremental height adjustment. To lower the seat, lift it beyond the highest setting, then allow it to drop to the lowest setting (Figure 14).



**Figure 14**

- **Backrest adjustment:** Pull the handle outward to adjust the seat backrest angle. Release the handle to lock the seat backrest in position (Figure 15).





**Figure 15**

1. Handle

# Warning Systems

## Engine-Coolant-Temperature-Warning Light

The engine-coolant-temperature-warning light illuminates, the horn is actuated, and the cutting units stop when the engine becomes too hot (Figure 16).



G034886

g034886



Figure 16

1. Engine-coolant-temperature-warning light

**Note:** The flail rotors disengage when the operating temperature reaches 115°C (239°F).

## Hydraulic-Fluid-Temperature-Warning Light

The hydraulic-fluid-temperature-warning light illuminates when overheating occurs and the horn is actuated when the hydraulic fluid in the reservoir exceeds 95°C (203°F); refer to Figure 17.



G034897



g034897

Figure 17

1. Hydraulic-fluid-temperature-warning light

## Battery-Charge-Warning Light

The battery-charge-warning light illuminates when the battery is low of charge (Figure 18).



G034887



g034887

Figure 18

1. Battery-charge-warning light

## Engine-Oil-Pressure-Warning Light

The engine-oil-pressure-warning light illuminates when the oil pressure is too low (Figure 19).



G034898

g034898

Figure 19



1. Engine-oil-pressure-warning light

## Audible Warning Horn

**Service Interval:** Before each use or daily—Check the horn.

Press the horn button to provide an audible warning (Figure 20).

**Important:** The horn is automatically actuated when an engine coolant or hydraulic fluid overheat condition occurs. Shut off the engine immediately and fix the machine before starting it again.



G034888

g034888

Figure 20

1. Horn

# Key Switch

|                             |
|-----------------------------|
| 0 = Engine off              |
| I = Engine run/Auxiliary on |
| II = Engine pre-heat        |
| III = Engine start          |




Figure 21

1. Key switch

# Engine Pre-Heat Indicator Light

Turn the key to position II. The engine preheat indicator light will illuminate and heat the glow plugs (Figure 22).

**Important:** Attempting to start a cold engine before the pre-heat is used can cause unnecessary wear to the battery.




Figure 22

1. Engine pre-heat indicator light

# Fuel Gauge

The fuel gauge shows the amount of fuel in the tank (Figure 23).




Figure 23

# Hour Meter

The hour meter shows the total hours that the machine has been operated (Figure 24).





Figure 24

1. Hour meter

# Transmission-Neutral-Indicator Light

This light illuminates when the travel-control pedal is in the NEUTRAL position and the ignition key is turned to position I (Figure 25).

**Note:** The parking brake must be engaged for the transmission neutral indicator light to illuminate.



G034894

g034894


**Figure 25**

1. Transmission-neutral-indicator light
- 

## Cutting-Unit-Drive-Switch-Indicator Light

This light illuminates when the cutting unit drive switch is On and the ignition key is turned to position I ([Figure 26](#)).

To engage the cutting unit drive, refer to [Engaging the Cutting Unit Drive](#) (page 27).



G034895

g034895

**Figure 26**

1. Cutting-unit-drive-switch-indicator light
-

# Specifications

**Note:** Specifications and design are subject to change without notice.

| Specification             | LT-F3000                                                        |
|---------------------------|-----------------------------------------------------------------|
| Transport Width           | 157.5 cm (62 inches)                                            |
| Width of cut              | 76 cm (30 inches) to 212 cm (83.5 inches)                       |
| Height of cut             | 20 mm (3/4 inch) to 75 mm (3 inches)                            |
| Length                    | 302.5 cm (119.1 inches)                                         |
| Height                    | 216 cm (85.0 inches) with ROPS<br>209 cm (82.3 inches) with cab |
| Weight                    | 1392 kg (3069 lb) with ROPS<br>1592 kg (3510 lb) with cab       |
| Engine                    | Kubota 32.8 kw (44 hp) at 3000 rpm DIN 70020                    |
| Fuel tank capacity        | 45 L (11.9 US gallons)                                          |
| Transport speed           | 25 km/h (15.5 mph)                                              |
| Mowing speed              | 11 km/h (6.85 mph)                                              |
| Hydraulic system capacity | 32 L (8.5 US gallons)                                           |
| Engine speed              | 3000 rpm                                                        |
| Rotor speed               | 3000 rpm                                                        |

## Attachments/Accessories

A selection of Toro approved attachments and accessories is available for use with the machine to enhance and expand its capabilities. Contact your Authorized Service Dealer or authorized Toro distributor or go to [www.Toro.com](http://www.Toro.com) for a list of all approved attachments and accessories.

To ensure optimum performance and continued safety certification of the machine, use only genuine Toro replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous, and such use could void the product warranty.

# Operation

## *Before Operation*

### Before Operation Safety

#### General Safety

- Never allow children or untrained people to operate or service the machine. Local regulations may restrict the age of the operator. The owner is responsible for training all operators and mechanics.
- Become familiar with the safe operation of the equipment, operator controls, and safety signs.
- Shut off the engine, remove the key, and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Know how to stop the machine and shut off the engine quickly.
- Do not operate the machine without all guards and other safety protective devices in place and functioning properly on the machine.
- Before mowing, always inspect the machine to ensure that the cutting units are in good working condition.
- Inspect the area where you will use the machine and remove all objects that the machine could throw.

#### Fuel Safety

- Use extreme care in handling fuel. It is flammable and its vapors are explosive.
- Extinguish all cigarettes, cigars, pipes, and other sources of ignition.
- Use only an approved fuel container.
- Do not remove the fuel cap or fill the fuel tank while the engine is running or hot.
- Do not add or drain fuel in an enclosed space.
- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.
- If you spill fuel, do not attempt to start the engine; avoid creating any source of ignition until the fuel vapors have dissipated.

## Performing Daily Maintenance

**Service Interval:** Before each use or daily

Before starting the machine each day, perform the Each Use/Daily procedures listed in [Maintenance \(page 32\)](#).

### Filling the Fuel Tank

#### Fuel Tank Capacity

45 L (11.9 US gallons)

#### Fuel Specification

Failure to observe the following cautions may damage the engine.

- Never use kerosene or gasoline instead of diesel fuel.
- Never mix kerosene or used engine oil with the diesel fuel.
- Never keep fuel in containers with zinc plating on the inside.
- Do not use fuel additives.

#### Petroleum Diesel

Use only clean, fresh diesel fuel or biodiesel fuels with low (<500 ppm) or ultra-low (<15 ppm) sulfur content. The minimum cetane rating should be 40. Purchase fuel in quantities that can be used within 180 days to ensure fuel freshness.

Use summer-grade diesel fuel (Number 2-D) at temperatures above -7°C (20°F) and winter-grade diesel fuel (Number 1-D or Number 1-D/2-D blend) below -7°C (20°F). Using winter-grade fuel at lower temperatures provides a lower flash point and cold-flow characteristics, which will ease starting and reduce fuel-filter plugging.

Using summer-grade fuel above -7°C (20°F) will contribute toward longer fuel-pump life and increased power compared to winter-grade fuel.

#### Adding Fuel

1. Park the machine on a level surface, lower the cutting units, engage the parking brake, shut off the engine, and remove the key.
2. Using a clean rag, clean the area around the fuel-tank cap.
3. Remove the cap from the fuel tank.
4. Fill the tank until the level is to the bottom of the filler neck with fuel.

5. Install fuel-tank cap tightly after filling tank.

**Note:** If possible, fill the fuel tank after each use. This minimizes possible buildup of condensation inside the fuel tank.

## ***During Operation***

### **During Operation Safety**

#### **General Safety**

- The owner/operator can prevent and is responsible for accidents that may cause personal injury or property damage.
- Wear appropriate clothing, including eye protection; long trousers; substantial, slip-resistant footwear; and hearing protection. Tie back long hair and do not wear loose clothing or loose jewelry.
- Do not operate the machine while ill, tired, or under the influence of alcohol or drugs.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Before you start the engine, ensure that all drives are in neutral, the parking brake is engaged, and you are in the operating position.
- Do not carry passengers on the machine and keep bystanders and children out of the operating area.
- Operate the machine only in good visibility to avoid holes or hidden hazards.
- Avoid mowing on wet grass. Reduced traction could cause the machine to slide.
- Keep your hands and feet away from the cutting units.
- Look behind and down before backing up to be sure of a clear path.
- Use care when approaching blind corners, shrubs, trees, or other objects that may obscure your vision.
- Stop the cutting units whenever you are not mowing.
- Slow down and use caution when making turns and crossing roads and sidewalks with the machine. Always yield the right-of-way.
- Operate the engine only in well-ventilated areas. Exhaust gases contain carbon monoxide, which is lethal if inhaled.
- Do not leave a running machine unattended.
- Before you leave the operator's position, do the following:

- Park the machine on a level surface.
- Disengage the cutting unit(s) and lower the attachments.
- Engage the parking brake.
- Shut off the engine and remove the key.
- Wait for all movement to stop.
- Operate the machine only in good visibility and appropriate weather conditions. Do not operate the machine when there is the risk of lightning.

#### **Rollover Protection System (ROPS) Safety**

- Do not remove any of the ROPS components from the machine.
- Ensure that the seat belt is attached and that you can release it quickly in an emergency.
- Always wear your seat belt.
- Check carefully for overhead obstructions and do not contact them.
- Keep the ROPS in safe operating condition by thoroughly inspecting it periodically for damage and keeping all the mounting fasteners tight.
- Replace all damaged ROPS components. Do not repair or alter them.

#### **Machines with a Foldable Roll Bar**

- Always use the seat belt with the roll bar in the raised position.
- The ROPS is an integral safety device. Keep a folding roll bar in the raised and locked position, and use the seat belt when operating the machine with the roll bar in the raised position.
- Lower a folding roll bar temporarily only when necessary. Do not wear the seat belt when the roll bar is folded down.
- Be aware that there is no rollover protection when a folded roll bar is in the down position.
- Check the area that you will be mowing and never fold down a folding roll bar in areas where there are slopes, drop-offs, or water.

#### **Slope Safety**

- Slopes are a major factor related to loss of control and rollover accidents, which can result in severe injury or death. You are responsible for safe slope operation. Operating the machine on any slope requires extra caution.
- Evaluate the site conditions to determine if the slope is safe for machine operation, including

surveying the site. Always use common sense and good judgment when performing this survey.

- Review the slope instructions, listed below, for operating the machine on slopes. Before you operate the machine, review the site conditions to determine whether you can operate the machine in the conditions on that day and at that site. Changes in the terrain can result in a change in slope operation for the machine.
  - Avoid starting, stopping, or turning the machine on slopes. Avoid making sudden changes in speed or direction. Make turns slowly and gradually.
  - Do not operate a machine under any conditions where traction, steering, or stability is in question.
  - Remove or mark obstructions such as ditches, holes, ruts, bumps, rocks, or other hidden hazards. Tall grass can hide obstructions. Uneven terrain could overturn the machine.
  - Be aware that operating the machine on wet grass, across slopes, or downhill may cause the machine to lose traction.
  - Use extreme caution when operating the machine near drop-offs, ditches, embankments, water hazards, or other hazards. The machine could suddenly roll over if a wheel goes over the edge or the edge caves in. Establish a safety area between the machine and any hazard.
  - Identify hazards at the base of the slope. If there are hazards, mow the slope with a pedestrian-controlled machine.
  - If possible, keep the cutting units lowered to the ground while operating on slopes. Raising the cutting units while operating on slopes can cause the machine to become unstable.

## Using the Operator Platform Latching Mechanism

Do not operate the mower without first checking that the operator platform latching mechanism is fully engaged and in good working order.

### **⚠ WARNING**

**Never operate the mower without first checking that the operator platform latching mechanism is fully engaged and in good working order.**

## Releasing the Platform

1. Move the locking latch handle towards the front of the mower until the latch hooks clear the locking bar.
2. Raise the platform. The gas spring will provide assistance.


## Securing the Platform

1. Lower the platform carefully.

**Note:** The gas spring will provide assistance.
2. Move the locking latch handle towards the front of the mower as the platform nears the fully lowered position.

**Note:** This will ensure that the latch hooks clear the locking bar.

3. Fully lower the platform and move the locking handle towards the rear of the mower until the latch hooks fully engage the locking bar.



G014422

g014422

Figure 27

## Understanding the Operator Presence Controls

**Note:** The engine stops if the operator leaves the seat without engaging the parking brake.

**Engine Start Lockout:** The engine can only be started when the forward/reverse travel pedal is in the **Neutral** position, the cutting unit drive switch is in the **Off** position and the parking brake is engaged. When these circumstances are satisfied, switches are activated permitting the engine to be started.

**Engine Run Interlock:** Once the engine is started the operator must be seated before the parking brake is disengaged for the engine to continue to run.

**Cutting Unit Drive Lockout:** The drive to the cutting units is only possible when the operator is seated. If the operator raises off the seat for a period of more than one second, a switch is activated and the drive to the cutting units is automatically disengaged. To engage the drive to the cutting units, the operator must return to the seat, then operate the cutting unit drive switch to the **Off** position before moving it back to the **On** position. If the operator rises off the seat for a brief moment during normal work, drive to the cutting units is not affected.

The engine can only be started with the cutting unit drive switch in the **Off** position.

### **⚠ WARNING**

Do not operate the turf mower if the operator presence controls are malfunctioning in any way. *Always* replace damaged or worn parts and check that they function correctly before operating the machine.

### **⚠ CAUTION**

If safety interlock switches are disconnected or damaged the machine could operate unexpectedly causing personal injury.

- Do not tamper with the interlock switches.
- Check the operation of the interlock switches daily and replace any damaged switches before operating the machine.

## Folding the Roll Bar

### **⚠ WARNING**

To avoid injury or death from rollover: keep the roll bar in the raised locked position and use the seat belt.

Ensure that the seat is secured with the seat latch.

### **⚠ WARNING**

There is no rollover protection when the roll bar is in the down position.

- Do not operate the machine on uneven ground or on a hill side with the roll bar in the down position.
- Lower the roll bar only when absolutely necessary.
- Do not wear the seat belt when the roll bar is in the down position.
- Drive slowly and carefully.
- Raise the roll bar as soon as clearance permits.
- Check carefully for overhead clearances (i.e., branches, doorways, electrical wires) before driving under any objects and do not contact them.

**Important:** Always use the seat belt when the roll bar is in the raised and locked position. Do not use the seat belt when the roll bar is in the lowered position.

1. Park the machine on a level surface, lower the cutting units, engage the parking brake, shut off the engine, and remove the key.
2. Support the weight of the upper frame of the roll bar while removing the snap pins and clevis pins from the pivot brackets (Figure 28).




Figure 28

- |                                   |                                    |
|-----------------------------------|------------------------------------|
| 1. Upper frame in raised position | 3. Lower holes                     |
| 2. Clevis pins and snap pins      | 4. Upper frame in lowered position |

g280225

3. Carefully lower the frame downward until it rests on the stops.
4. Insert the clevis pins in the lower holes and secure them with the snap pins to support the upper frame in its lowered position.
5. To raise the frame, follow these instructions in reverse order.

## Checking the Interlock Switches

### Checking the Forward/Reverse Travel Pedal Action

With the engine shut off, operate the forward and reverse travel pedals through the full range of articulation and ensure that the mechanism returns freely to the neutral position.

### Checking the Operator Presence Seat Switch

**Service Interval:** Before each use or daily

1. Sit on the operator seat and start the engine.
2. Lower the cutting units to the ground.
3. Engage that the cutting unit drive in the forward direction.
4. Rise from the operator seat and check that the cutting units come to a stop after an initial 0.5 to 1 second delay.

### Checking the Cutting Unit Drive Interlock Switch

1. Shut off the engine.
2. Operate the cutting unit drive switch to the off position and turn the ignition key to position I. The cutting unit drive switch indicator light should not illuminate.
3. Operate the switch to the forward position. The indicator light should illuminate and the engine should not start when the ignition key is turned. Repeat for the reverse position.

### Checking the Parking Brake Interlock Switch

1. Shut off the engine.
2. Engage the parking brake.
3. Turn the ignition key to position I. The parking brake indicator light should illuminate.

4. Disengage the parking brake. The indicator light should go out and the engine should not start when the ignition key is turned.
5. Engage the parking brake, sit on the operator seat, and start the engine.
6. Disengage the parking brake.
7. Rise from the operator seat and check that the engine shuts off.

## Checking the Transmission Neutral Interlock Switch

1. Shut off the engine.
2. Remove your foot from the forward/reverse travel pedals.
3. Turn the ignition key to position I and the transmission neutral indicator light should illuminate.
4. Apply light pressure to the travel pedals in a forward and reverse direction to check that the indicator light turns off.

**Note:** Take extreme care to ensure that the area around the machine is clear before checking that the engine will not start under this condition.

## Starting the Engine

**Important:** You must bleed the fuel system before starting the engine if you are starting the engine for the first time, the engine has stopped due to lack of fuel, or you have performed maintenance on the fuel system; refer to [Bleeding the Fuel System \(page 39\)](#).

**Important:** This machine is fitted with an engine start lockout; refer to [Understanding the Operator Presence Controls \(page 22\)](#).

1. Sit on the seat, keep your foot off the traction pedals so that it is in NEUTRAL, ensure that the cutting unit drive switch is off, engage the parking brake, and set the throttle to the 70 percent full-throttle position.
2. Turn the key to the on position I and check that the engine oil pressure and battery charge warning lights illuminate.
3. If the engine is cold, turn the key to the preheat position II so that the pre-heat indicator light is on ([Figure 22](#)). Hold it for 5 seconds to heat the glow plugs.
4. After preheating the glow plugs or if the engine is already warm, turn the key to the start position III and hold it there to crank the engine.

Crank the engine for no longer than 15 seconds. Release the key back to position I when the engine starts.

5. Run the engine at low idle speed until it warms up.

**Important:** When the engine is operating all warning lights should be off. If a warning light illuminates, shut off the engine immediately and fix the issue before starting the engine.

## Shutting Off the Engine

### ⚠ WARNING

**Keep hands clear of moving objects and hot engine parts while the engine is running.**

1. Move all controls to NEUTRAL, engage the parking brake, move the throttle to the low idle position and allow the engine to reach low idle speed.

**Important:** Allow the engine to idle for 5 minutes before shutting it off after a full load operation. Failure to do so may lead to trouble on a turbo-charged engine.

2. Let the engine idle for 5 minutes.
3. Turn the key to position 0.

If the engine fails to shut off when the key is turned to 0, operate the engine shutoff lever in the forward direction (Figure 29).




Figure 29

g014563

## Flail Cutting Unit General Information

It is important to keep the flail blades sharp and in good condition to ensure good cutting performance,

minimum power consumption, and a good quality of cut.

The flail head is a fine cut flail and should only be used for maintaining grass. Its recommended that a maximum of 1/3 of the total grass length is removed when cut.

The scraper wires are fitted to remove debris from the roller, in dry conditions these may not be required and its recommended they are removed. In damp wet conditions ensure that scraper wires do not get plugged with debris.

The cutting unit floats and can pivot laterally to follow ground contours.

The cutting units are designed to be operated at full engine rpm. Forward speed should be adjusted depending on grass conditions and to not overload the power units or the heads. The lower the forward speed the higher the quality of cut and after cut appearance.

## Adjusting the Height of Cut

**Note:** The height of cut is gauged by the rear roller. Blade wear, worn cutting unit pivots, bent/damaged cutting unit pins, and bent/damaged arms can affect the height-of-cut setting.

1. Turn the adjusting-nut assembly on both ends clockwise to decrease the height of cut or counter-clockwise to increase the height of cut (Figure 30).




Figure 30


g034595

1. Height of cut

2. Adjusting-nut assembly

**Important:** Do not attempt to unlock the nut assemblies.


2. Ensure that all cutting units are set at the same height of cut by referring to the indicator rings (Figure 31).



**Figure 31**

1. Indicator rings

**Note:** Refer to [Figure 32](#) for the height-of-cut settings.



**Figure 32**


- |                       |                        |
|-----------------------|------------------------|
| 1. 75 mm (3.0 inches) | 4. 40 mm (1.5 inches)  |
| 2. 65 mm (2.5 inches) | 5. 25 mm (1.0 inches)  |
| 3. 50 mm (2.0 inches) | 6. 20 mm (0.75 inches) |

## Controlling the Position of the Individual Cutting Units

The cutting units may be raised or lowered independently using the bank of 3 lift-control switches.

1. To lower the cutting units, operate the lift-control switches in a downward direction and release.

**Note:** The cutting-unit-drive switch must be on to do this, the flail rotor drive engages when the cutting units are approximately 150 mm (6 inches) above ground level. The cutting units are now in 'float' mode and follow the ground contours.



**Figure 33**

1. Lift-control switches

2. To raise the cutting units, operate the lift-control switches in an upward direction and hold in position 3. If the cutting-unit-drive switch is in the ON position the flail rotor drive disengages.
3. Release the lift-control switches when the cutting units are at the required height.

**Note:** The control switches automatically return to position 2 (NEUTRAL) and the arms are hydraulically locked into position.

**To raise the cutting units to the limited lift position:** momentarily operate the switches in an upward direction.

The flail rotor drive disengages immediately and the cutting units stop raising, approximately 150 mm (6 inches) above ground level.

This operates with the cutting units lowered and rotating.

Auto limited lift in reverse causes the cutting units to rise automatically to the limited lift position when reversing. They return to the floating position when returning to forward travel. The flail rotors continue to rotate during this operation.

## Using the Cutting Unit Auto-Limited Lift in Reverse

To activate, press the auto-limited-lift switch to the ON position ([Figure 34](#)).

To deactivate, press the auto-limited-lift switch to the OFF position ([Figure 34](#)).

Manual limited lift using the 3 lift-control switches is always available regardless of the position of the auto switch.




Figure 34

the lift-control switch(s) in a downward direction. The machine drives when the cutting units are approximately 150 mm (6 inches) above ground level.

## Using Weight-Transfer/Traction Assistance

A variable hydraulic weight transfer system is provided for improving tire grip with the grass surface—traction assistance.

Hydraulic pressure in the cutting units lift system provides a lifting force which reduces the weight of the cutting units on the ground and transfers the weight as a downward force onto the tires of the machine. This action is known as weight transfer.

**To engage weight transfer:** The amount of weight transfer can be varied to suit operating conditions by rotating the weight-transfer hand wheel (Figure 36) as follows:

1. Release the valve locknut 1/2 turn counterclockwise and hold (Figure 36).
2. Rotate the valve hand wheel (Figure 36) counterclockwise to reduce weight transfer or clockwise to increase weight transfer.
3. Tighten the nut.

**Note:** The recommended setting is to increase weight transfer until heads start to lift, then back off 1/2 turn, and lock.




Figure 36

1. Lock wheel
2. Weight-transfer hand wheel

## Engaging the Cutting Unit Drive




Figure 35

1. On
2. Off

The cutting unit drive can be engaged only when the operator is seated correctly, refer to [Checking the Operator-Presence-Seat Switch](#) (page 46).

**Cutting unit drive engagement:** Press the top of the cutting-unit-drive switch to the on position (Figure 35).

**All cutting unit drives disengagement:** Set the switch to the off position (Figure 35).

**To lower the cutting units:** The cutting unit drive switch must be set to the on position. Operate

# Operating Tips

## Becoming Familiar with the Machine

Before mowing grass, practice operating the machine in an open area. Start and shut off the engine. Operate in forward and reverse. Lower and raise the cutting units and engage and disengage the cutting units. When you feel familiar with the machine, practice operating up and down slopes at different speeds.

## Understanding the Warning System

If a warning light comes on during operation, stop the machine immediately and correct the problem before continuing operation. Serious damage could occur if you operate the machine with a malfunction.

## Mowing Grass

The rotational speed of the flail rotors should always be kept as high as possible in order to maintain the highest quality of cut. This in turn requires that the engine speed be kept as high as possible.

Cutting performance is best when cutting against the lie of the grass. In order to take advantage of this fact, the operator should attempt to alternate the direction of mowing between cuts.

Take care not to leave uncut strips of grass at the overlap points between adjacent cutting units by avoiding tight turns.

## Maximizing the Quality of Cut

The quality of cut deteriorates if the forward speed is excessive. Always balance the quality of cut with the work rate required and set the forward speed accordingly.

## Maximizing Engine Efficiency

Do not let the engine labor. If you notice that the engine starts to labor, reduce the forward speed or increase the height of cut. Check to make sure that the flail blades are sharp.

## Driving the Machine in Transport Mode

Always disengage the cutting unit drive when travelling across un-grassed areas. Be careful when

driving between objects so that you do not accidentally damage the machine or the cutting units.

### **⚠ WARNING**

**Take care when travelling over obstacles such as roadside curbs as such obstacles may allow the machine to rollover which may cause severe injury.**

**Always travel at slow speed over obstacles to prevent damage to the tires, wheels, and steering system. Ensure that the tires are inflated to the recommended pressures.**

## Operating the Machine on Slopes

Use extra care when operating the machine on slopes. Drive slowly and avoid sharp turns on slopes to prevent rollovers. Lower the cutting units for steering control when going downhill.

## Using the Rear Roller Scrapers

It is generally wise to remove rear roller scrapers where conditions allow, as optimum grass discharge is achieved without them. Install the scrapers when conditions are such that mud and grass start to buildup on the rollers. When installing the scraper wires, ensure that they are correctly tensioned.

## *After Operation*

## After Operation Safety

### General Safety

- Shut off the engine, remove the key, and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Clean grass and debris from the cutting units, drives, mufflers, cooling screens, and engine compartment to help prevent fires. Clean up oil or fuel spills.
- Shut off the fuel while storing or hauling the machine.
- Disengage the drive to the attachment whenever you are hauling or not using the machine.
- Maintain and clean the seat belt(s) as necessary.
- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or on other appliances.

# Identifying the Tie-Down Points




Figure 37

1. Front tie-down point      2. Rear tie-down point

## Hauling the Machine

- Use full-width ramps for loading the machine onto a trailer or truck.
- Tie the machine down securely.

## Locating the Jacking Points


**Note:** Use jack stands to support the machine when required.

### ⚠ WARNING

**Mechanical or hydraulic jacks may fail to support the machine and cause serious injury.**

**Use jack stands when supporting the machine.**

- Front—under the front arm mount
- Rear—axle tube on the rear axle



G0144447

g014447

Figure 38

1. Front left lifting point      3. Rear lifting point  
2. Front right lifting point


## Towing the Machine

Ensure that the towing vehicle specification is suited to braking the combined vehicle weight and able to remain in complete control at all times. Ensure that the parking brake of the towing vehicle is engaged. Chock the front wheels of the machine to prevent the machine from rolling away.

**Important:** Do not tow the machine faster than 3 to 5 km/h (2 to 3 mph), otherwise internal transmission damage may occur.

**Decommission the front wheel motor disc brakes as follows:**


1. Connect a **rigid** tow bar between the towing eye on the front of the mower and a suitable towing vehicle.
2. Identify the right front wheel motor disc brake assembly and remove the hex plug (Figure 39).



**Figure 39**

1. Hex plug

3. Locate the M12 x 40 mm setscrew and washer stored underneath the operator platform, one in each of the platform support rails.
4. Install a M12 x 40 mm long setscrew with washer into the hole in the center of the motor end plate ([Figure 40](#)).




**Figure 40**

1. Hex plug
2. Washer M12
3. Setscrew M12 x 40

5. Tighten the setscrew into the threaded hole in the brake piston until the brake is released ([Figure 40](#)).
6. Identify the left front wheel motor disc brake assembly and repeat the previous procedure ([Figure 40](#)).
7. Decommission the hydraulic service braking system by turning the bypass valve, located under the transmission pump, counterclockwise, a maximum of 3 turns ([Figure 41](#)).

The steering must be operated manually when the mower is being towed. The steering will feel

heavy as there is no hydraulic assistance when the engine is shut off.



**Figure 41**

1. Transmission bypass valves

8. The mower is now in a freewheel condition and can be towed for a short distance at slow speed.


**Note:** Remove the wheel chocks before towing.

9. **After towing the mower:** To return the mower to its normal working condition the following procedure must be done:
  - A. Chock the front wheels.
  - B. Close the bypass valve on the transmission pump by turning it clockwise.

10. **Commission the front wheel motor disc brakes as follows:**

**Note:** Ensure that the M12 x 40 mm setscrews and washers are removed and stored underneath the operator platform.

- A. Identify the right front wheel motor disc brake assembly.
- B. Rotate the setscrew counterclockwise and remove together with the washer.
- C. Assemble the hex plug into the motor end plate ([Figure 42](#)).



**Figure 42**

- |                     |                         |
|---------------------|-------------------------|
| 1. Front wheel moto | 3. Washer M12           |
| 2. Hex plug         | 4. Setscrew M12 x 40 mm |

- D. Identify the left front wheel motor disc brake assembly and repeat the previous procedure.
- E. Remove the wheel chocks.
- F. Disconnect the tow bar.

**Note:** The mower braking system will now operate in the normal way.

## **⚠ WARNING**

**Before using the mower, ensure that the braking system operates correctly. Carry out initial checks with the mower at slow speed. Do not operate the mower with a damaged braking system. Do not operate the mower with the brakes decommissioned.**

# Maintenance

**Note:** Determine the left and right sides of the machine from the normal operating position.

## Maintenance Safety

- Before you leave the operator's position, do the following:
  - Park the machine on a level surface.
  - Disengage the cutting unit(s) and lower the attachments.
  - Engage the parking brake.
  - Shut off the engine and remove the key.
  - Wait for all movement to stop.
- Allow machine components to cool before performing maintenance.
- If possible, do not perform maintenance while the engine is running. Keep away from moving parts.
- Support the machine with jack stands whenever you work under the machine.
- Carefully release pressure from components with stored energy.
- Keep all parts of the machine in good working condition and all hardware tightened.
- Replace all worn or damaged decals.
- To ensure safe, optimal performance of the machine, use only genuine Toro replacement parts. Replacement parts made by other manufacturers could be dangerous, and such use could void the product warranty.

# Recommended Maintenance Schedule(s)

| Maintenance Service Interval | Maintenance Procedure                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| After the first 8 hours      | <ul style="list-style-type: none"> <li>• Check the condition and tension of the alternator belt.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| After the first 50 hours     | <ul style="list-style-type: none"> <li>• Change the engine oil and filter.</li> <li>• Change the transmission-oil filter.</li> <li>• Change the hydraulic-return filter.</li> <li>• Check the engine speed (idle and full throttle).</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Before each use or daily     | <ul style="list-style-type: none"> <li>• Check the horn.</li> <li>• Inspect the seat belt(s) for wear, cuts, and other damage. Replace the seat belt(s) if any component does not operate properly.</li> <li>• Check the safety interlock system.</li> <li>• Check the tire pressure.</li> <li>• Grease the bearings, bushings, and pivots (grease them immediately after every washing regardless of the interval listed).</li> <li>• Check the air-cleaner-blockage indicator (service the air cleaner earlier if the air-cleaner indicator shows red; service it more frequently in extremely dirty or dusty conditions).</li> <li>• Check the engine-oil level.</li> <li>• Drain water or other contaminants from the water separator.</li> <li>• Check the torque the wheel-lug nuts.</li> <li>• Remove debris from the screen, oil coolers, and radiator (more frequently in dirty operating conditions).</li> <li>• Check the safety-interlock system.</li> <li>• Check the hydraulic lines and hoses.</li> <li>• Check the hydraulic-fluid level.</li> <li>• Check the height-of-cut setting.</li> <li>• Inspect the flail rotors and blades for damage, cracks, and loose fasteners. Replace any damaged or cracked parts.</li> <li>• Check the rear guard.</li> <li>• Check the front rubber guard.</li> <li>• Check the cutting unit pivot.</li> <li>• Check for any unusual vibration of the rotor.</li> <li>• Check the fasteners of the machine.</li> <li>• Check the cutting units.</li> <li>• Check the forward/reverse travel pedal action.</li> </ul> |
| Every 50 hours               | <ul style="list-style-type: none"> <li>• Grease the bearings, bushings, and pivots (grease them immediately after every washing regardless of the interval listed).</li> <li>• Check the blade bolts.</li> <li>• Inspect the blades for damage and excessive wear.</li> <li>• Make sure that each blade bolt is torqued to 45 N·m (33.2 ft-lb).</li> <li>• Check the cutting unit pivot.</li> <li>• Check for excessive play in the rotor bearings.</li> <li>• Check the rear-roller adjustment.</li> <li>• Check the rear-roller scraper wire tension.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Every 100 hours              | <ul style="list-style-type: none"> <li>• Inspect the cooling system hoses.</li> <li>• Check the condition and tension of the alternator belt.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Every 150 hours              | <ul style="list-style-type: none"> <li>• Change the engine oil and filter.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Every 250 hours              | <ul style="list-style-type: none"> <li>• Check the condition of the battery.</li> <li>• Check the condition of and clean the battery.</li> <li>• Check the battery cable connections.</li> <li>• Check the transmission-control cable.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Every 400 hours              | <ul style="list-style-type: none"> <li>• Check the fuel lines and connections.</li> <li>• Check the engine speed (idle and full throttle).</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

| Maintenance Service Interval | Maintenance Procedure                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Every 500 hours              | <ul style="list-style-type: none"> <li>• Check the engine overheat warning system.</li> <li>• Replace the primary air filter (more frequently in extreme dusty or dirty conditions).</li> <li>• Replace the fuel-filter canister.</li> <li>• Check the electrical system.</li> <li>• Change the transmission-oil filter.</li> <li>• Change the hydraulic-return filter.</li> <li>• Check the rear-wheel alignment.</li> <li>• Service the hydraulic system.</li> <li>• Check the hydraulic-fluid-overheat warning system.</li> </ul> |
| Every 800 hours              | <ul style="list-style-type: none"> <li>• Drain and clean the fuel tank.</li> <li>• Adjust the engine valves (refer to the engine operator's manual).</li> </ul>                                                                                                                                                                                                                                                                                                                                                                      |
| Before storage               | <ul style="list-style-type: none"> <li>• Drain and clean the fuel tank.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Yearly                       | <ul style="list-style-type: none"> <li>• Replace the blades.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Every 2 years                | <ul style="list-style-type: none"> <li>• Flush and replace the cooling system fluid.</li> <li>• Replace all moving hoses.</li> <li>• Replace the transmission cable.</li> </ul>                                                                                                                                                                                                                                                                                                                                                      |

# Daily Maintenance Checklist

Duplicate this page for routine use.

| Maintenance Check Item                                                                                 | For the week of: |       |      |        |      |      |      |
|--------------------------------------------------------------------------------------------------------|------------------|-------|------|--------|------|------|------|
|                                                                                                        | Mon.             | Tues. | Wed. | Thurs. | Fri. | Sat. | Sun. |
| Check the safety interlock operation.                                                                  |                  |       |      |        |      |      |      |
| Check the brake operation.                                                                             |                  |       |      |        |      |      |      |
| Check the engine oil and fuel level.                                                                   |                  |       |      |        |      |      |      |
| Check the air filter restriction indicator.                                                            |                  |       |      |        |      |      |      |
| Check the radiator and screen for debris.                                                              |                  |       |      |        |      |      |      |
| Check unusual engine noises. <sup>1</sup>                                                              |                  |       |      |        |      |      |      |
| Check unusual operating noises.                                                                        |                  |       |      |        |      |      |      |
| Check the hydraulic system oil level.                                                                  |                  |       |      |        |      |      |      |
| Check hydraulic hoses for damage.                                                                      |                  |       |      |        |      |      |      |
| Check for fluid leaks.                                                                                 |                  |       |      |        |      |      |      |
| Check the tyre pressure.                                                                               |                  |       |      |        |      |      |      |
| Check the instrument operation.                                                                        |                  |       |      |        |      |      |      |
| Check the rotor and blades.                                                                            |                  |       |      |        |      |      |      |
| Check the height-of-cut adjustment.                                                                    |                  |       |      |        |      |      |      |
| Check all grease fittings for lubrication. <sup>2</sup>                                                |                  |       |      |        |      |      |      |
| Touch-up damaged paint.                                                                                |                  |       |      |        |      |      |      |
| Wash the machine.                                                                                      |                  |       |      |        |      |      |      |
| 1. Check the glow plug and injector nozzles if hard starting, excess smoke, or rough running is noted. |                  |       |      |        |      |      |      |
| 2. Immediately after every washing, regardless of the interval listed                                  |                  |       |      |        |      |      |      |

## Notation for Areas of Concern

| Inspection performed by: |      |             |
|--------------------------|------|-------------|
| Item                     | Date | Information |
| 1                        |      |             |
| 2                        |      |             |
| 3                        |      |             |
| 4                        |      |             |
| 5                        |      |             |
| 6                        |      |             |
| 7                        |      |             |
| 8                        |      |             |

**Important:** Refer to your engine operator's manual for additional maintenance procedures.

**Note:** Download a free copy of the electrical or hydraulic schematic by visiting [www.Toro.com](http://www.Toro.com) and searching for your machine from the Manuals link on the home page.

# Lubrication

## Greasing the Bearings, Bushings, and Pivots

**Service Interval:** Before each use or daily

Every 50 hours

Lubricate all grease fittings for the bearings and bushings with No. 2 lithium grease. Lubricate the

bearings and bushings **immediately** after every washing, regardless of the interval listed.

Replace any damaged grease fittings.

**Important:** Use 1 pump of grease on the height-of-cut adjusters and 3 pumps of grease on all other grease fittings.

The grease fitting locations and quantities are as follows:




Figure 43

1. ● – Grease every 50 hours

2. ○ – Grease daily


## Engine Maintenance

### Engine Safety

- Shut off the engine before checking the oil or adding oil to the crankcase.
- Do not change the governor speed or overspeed the engine.

## Checking the Engine Overheat Warning System

**Service Interval:** Every 500 hours



**Figure 44**

1. Temperature switch

1. Turn the ignition key to the ignition on position I.
2. Disconnect the red/blue wire terminal from the engine-temperature switch.
3. Touch the metal terminal of this wire onto a suitable earth point, ensuring that the metal surfaces make good contact.

The horn sounds and the engine-coolant-temperature-warning light illuminates to confirm correct operation. If the system is malfunctioning, make repairs before operating the mower.

## Servicing the Air Cleaner

**Service Interval:** Before each use or daily  
Every 500 hours


### Servicing the Primary Air Filter

Check the air-cleaner body for damage which could cause an air leak. Replace if damaged. Check the whole intake system for leaks, damage or loose hose clamps.

Service the primary air-cleaner filter only when the service indicator ([Figure 45](#)) requires it. Changing the air filter before it is necessary only increases the chance of dirt entering the engine when the filter is removed.

**Important:** Be sure that the cover is seated correctly and seals with the air-cleaner body.

1. Check the filter-blockage indicator. If the indicator is red, the air filter needs to be cleaned or replaced ([Figure 45](#)).




G014565

g014565

**Figure 45**

2. Before removing the filter, use low pressure air (40 psi, clean and dry) to help remove large accumulations of debris packed between outside of the filter and the canister. **Avoid using high-pressure air which could force dirt through the filter into the intake tract.**

**Note:** This cleaning process prevents debris from migrating into the intake when the filter is removed.



g022394

g022394

**Figure 46**

1. Rubber outlet valve
2. Removable cover
3. Air filter

3. Remove the cover from the air-cleaner body.
4. Remove and replace the filter ([Figure 46](#)).  
Cleaning of the used element is not recommended due to the possibility of damage to the filter media.
5. Inspect the new filter for shipping damage, checking the sealing end of the filter and the body. **Do not use a damaged element.**
6. Insert the new filter by applying pressure to the outer rim of the element to seat it in the canister. **Do not apply pressure to the flexible center of the filter.**
7. Clean the dirt ejection port located in the removable cover. Remove the rubber outlet valve from the cover, clean the cavity and replace the outlet valve.

8. Install the cover orienting the rubber outlet valve in a downward position—between approximately 5 o'clock to 7 o'clock when viewed from the end.
9. Check the condition of the air-cleaner hoses.
10. Secure the cover.

## Servicing the Safety Filter

The air filter has a secondary, safety filter element inside the primary air filter to prevent dislodged dust and other items from entering the engine while changing the main element.

Replace the safety filter, never clean it.

**Important:** Never attempt to clean the safety filter. If the safety filter is dirty, then the primary filter is damaged. Replace both filters.

## Checking the Engine-Oil Level

**Service Interval:** Before each use or daily

The engine is shipped with oil in the crankcase; however, the oil level must be checked before and after the engine is first started.

**Crankcase capacity:** approximately 6.7 L (7.1 US qt) with the filter


Use high-quality engine oil that meets the following specifications:

- API Classification Level Required: CH-4, CI-4 or higher
- Preferred oil: SAE 15W-40 (above 0°F)
- Alternate oil: SAE 10W-30 or 5W-30 (all temperatures)

Toro Premium Engine oil is available from your distributor in either 15W-40 or 10W-30 viscosity.

**Note:** The best time to check the engine oil is when the engine is cool before it has been started for the day. If it has already been run, allow the oil to drain back down to the sump for at least 10 minutes before checking.

1. Park the machine on a level surface, lower the cutting units, engage the parking brake, shut off the engine, and remove the key.
2. Open the hood.
3. Remove the dipstick, wipe it clean, and install it (Figure 47).



**Figure 47**


1. Dipstick

4. Remove dipstick and check oil level on dipstick.

**Note:** The oil level should be up to the FULL mark.

5. If the oil level is below the FULL mark, remove the fill cap (Figure 48) and add oil until level reaches the FULL mark on dipstick.

**Important:** Do not overfill.



**Figure 48**

1. Oil-fill cap

6. Install the oil-fill cap and close the hood.

## Servicing the Engine Oil and Filter

**Service Interval:** After the first 50 hours

Every 150 hours

1. Remove the drain plug ([Figure 49](#)) and let the oil flow into a drain pan.




Figure 49

1. Oil-drain plug

2. When the oil stops, install the drain plug.
3. Remove the oil filter ([Figure 50](#)).




Figure 50

1. Oil filter

4. Apply a light coat of clean oil to the new filter seal.
5. Install the replacement oil filter to the filter adapter. Turn the oil filter clockwise until the rubber gasket contacts the filter adapter, then tighten the filter an additional 1/2 turn.

**Important:** Do not overtighten the filter.

6. Add oil to the crankcase; refer to [Checking the Engine-Oil Level \(page 38\)](#).

## Fuel System Maintenance

### ⚠ DANGER

Under certain conditions, fuel and fuel vapors are highly flammable and explosive. A fire or explosion from fuel can burn you and others and can cause property damage.

- Fill the fuel tank outdoors, in an open area, when the engine is off and is cold. Wipe up any fuel that spills.
- Do not fill the fuel tank completely full. Add fuel to the fuel tank until the level is 25 mm (1 inch) below the top of the tank, not the filler neck. This empty space in the tank allows the fuel to expand.
- Never smoke when handling fuel, and stay away from an open flame or where fuel fumes may be ignited by a spark.
- Store fuel in a clean, safety-approved container and keep the cap in place.

## Draining the Fuel Tank

**Service Interval:** Every 800 hours

Before storage

Drain and clean the fuel tank if the fuel system becomes contaminated or if the machine is to be stored for an extended period. Use clean fuel to flush out the tank.

## Checking the Fuel Lines and Connections

**Service Interval:** Every 400 hours/Yearly (whichever comes first)

Check the fuel lines and connections. Inspect them for deterioration, damage, or loose connections.

## Bleeding the Fuel System

You must bleed the fuel system before starting the engine if any of the following situations have occurred:

- Initial start-up of a new machine.
  - Engine has ceased running due to lack of fuel.
  - Maintenance has been performed upon fuel system components; i.e., filter replaced, separator serviced, etc.
1. Park the machine on a level surface and ensure that the fuel tank is at least half full.

2. Open the hood.
3. Turn the key in the ignition switch to the ON position and crank the engine.

**Note:** The mechanical pump sucks fuel out of the tank, fill the fuel filter and fuel hose and force the air into the engine. This could take some time to fully purge all the air out of the system and the engine might fire erratically until all air is purged out. When all air is purged and the engine is running smoothly, it should be run for a few minutes to ensure that it is fully purged.

## Replacing the Fuel Filter

**Service Interval:** Every 500 hours


Before each use or daily—Drain water or other contaminants from the water separator.

**Important:** Replace the fuel-filter canister periodically to prevent wear of the fuel-injection-pump plunger or the injection nozzle, due to dirt in the fuel.

1. Place a clean container under the fuel-filter canister ([Figure 51](#)).

**Note:** The fuel-filter canister is located near the battery under the engine cover.

2. Loosen the drain plug on the bottom of the filter canister.
3. Clean the area where the filter canister mounts.



**Figure 51**

1. Fuel-filter canister

- 
4. Remove the filter canister and clean the mounting surface.
  5. Lubricate the gasket on the filter canister with clean oil.
  6. Install the new filter canister by hand until the gasket contacts mounting surface and then rotate it an additional 1/2 turn.
  7. Tighten the drain plug on the bottom of the filter canister.
  8. Bleed the fuel system; refer to [Bleeding the Fuel System \(page 39\)](#).

# Electrical System Maintenance

## Electrical System Safety

- Disconnect the battery before repairing the machine. Disconnect the negative terminal first and the positive last. Connect the positive terminal first and the negative last.
- Charge the battery in an open, well-ventilated area, away from sparks and flames. Unplug the charger before connecting or disconnecting the battery. Wear protective clothing and use insulated tools.

## Checking the Electrical System

**Service Interval:** Every 500 hours

Inspect all electrical connections and cables and replace any which are damaged or corroded. Spray a good-quality water inhibitor onto exposed connections to prevent moisture ingress.

## Checking the Battery Condition

**Service Interval:** Every 250 hours

**Note:** When removing the battery, always disconnect the negative (-) cable first.

**Note:** When installing the battery, always connect the negative (-) cable last.

Raise the engine cover. Remove any corrosion from the battery terminals using a wire brush and apply petroleum jelly to the terminals to prevent further corrosion. Clean the battery compartment.

Under normal operating conditions the battery does not require any further attention. If the machine has been subject to continuous use under high ambient temperature conditions, the battery electrolyte may require topping up.

Remove the cell covers and top up with distilled water to a height 15 mm below the top of the battery. Install the cell covers.

**Note:** Check the condition of the battery cables. Install new cables when current ones are showing signs of wear or damage and tighten any loose connections as necessary.

## Servicing the Battery

**Service Interval:** Every 250 hours

### ⚠ DANGER

Battery electrolyte contains sulfuric acid which is a deadly poison and causes severe burns.

- Do not drink electrolyte and avoid contact with skin, eyes, or clothing. Wear eye protection to shield your eyes and rubber gloves to protect your hands.
- Fill the battery where clean water is always available for flushing the skin.

### ⚠ WARNING

Charging the battery produces gasses that can explode.

**Never smoke near the battery and keep sparks and flames away from it.**

Check the battery condition. Keep the terminals and the entire battery case clean because a dirty battery discharges slowly. To clean the battery, wash the entire case with a solution of baking soda and water. Rinse it with clear water.

# Drive System Maintenance

## Checking the Tire Pressure

Check the air pressure in the front and rear tires. Refer to the chart below for the correct pressure.

**Important:** Maintain correct tire pressure in all tires to ensure correct contact with the turf.

Recommended tire pressure is 1 bar (14.5 psi) for general all around use. Tire pressures can be adjusted according to the following table depending on operating conditions.

| Tires      | Tire Type                       | Recommended Tire Pressures |                  |                  |
|------------|---------------------------------|----------------------------|------------------|------------------|
|            |                                 | Turf Conditions            | Road Conditions  | Maximum Pressure |
| Front Axle | 26 x 12.0 - 12 BKT turf pattern | 0.7 bar (10 psi)           | 1.4 bar (20 psi) | 1.7 bar (25 psi) |
| Rear Axle  | 20 x 10.0 - 8 BKT turf pattern  | 0.7 bar (10 psi)           | 1.4 bar (20 psi) | 1.7 bar (25 psi) |

## Checking the Torque of the Wheel-Lug Nuts

**Service Interval:** Before each use or daily

Torque the wheel-lug nuts to 200 N·m (148 ft-lb) for the front axle, and 54 N·m (40 ft-lb) for the rear axle.

### ⚠ WARNING


Failure to maintain proper torque of the wheel nuts could result in personal injury.

Ensure that the wheel nuts are torqued properly.

# Changing the Transmission Oil Filter

**Service Interval:** After the first 50 hours

Every 500 hours



**Figure 52**

Right Side of Machine

1. Transmission-oil filter


1. Unscrew and remove the bottom of the transmission-oil-filter housing.
2. Withdraw the filter element and discard it.
3. Install a new filter element.
4. Install the housing.

## Changing the Hydraulic-Return Filter

**Service Interval:** After the first 50 hours

Every 500 hours

1. Remove the return filter.
2. Wipe oil onto the new return filter gasket.
3. Install the new return filter to the machine.



**Figure 53**  
Left Side of Machine


1. Hydraulic-fluid-return filter

## Checking the Rear-Wheel Alignment

**Service Interval:** Every 500 hours

To prevent excessive tire wear and ensure safe machine operation, the rear wheels must be correctly aligned to 3 to 8 mm (0.12 to 0.31 inch).

Set the rear wheels in the straight ahead position. Measure and compare the distance between the front sidewalls and the rear sidewalls at the wheel center height. The distance between the front sidewalls must be set 3 to 8 mm (0.12 to 0.31 inch) less than the distance between the rear sidewalls.



**Figure 54**

1. Wheel center height
2. Tire
3. Direction of forward travel
4. Track-rod assembly

To adjust the alignment of the rear wheels, first back off the left and right locknuts on the track rod


assembly. (Left locknut has a left thread). Rotate the track rod to achieve the correct distance as described above and tighten the locknuts securely.

## Inspecting the Transmission Control Cable and Operating Mechanism

**Service Interval:** Every 250 hours

Check the condition and security of the cable and operating mechanism at the speed-control pedals and transmission pump ends.

- Remove buildup of dirt, grit and other deposits.
- Ensure that the ball joints are securely anchored and check that the mounting brackets and cable anchors are tight and free from cracks.
- Inspect end fittings for wear, corrosion, broken springs, and replace if necessary.
- Ensure that the rubber seals are correctly located and are in good condition.
- Ensure that the articulating sleeves supporting the inner cable are in good condition and firmly attached to the outer cable assembly at the crimped connections. If there are any signs of cracking or detachment install a new cable immediately.
- Check that sleeves, rods, and inner cable are free from bends, kinks, or other damage. If they are not, install a new cable immediately.
- With the engine shut off, operate the pedal controls through the entire range and ensure that the mechanism moves smoothly and freely to the neutral position without sticking or hanging up.




**Figure 55**

1. Outer cover
2. Rubber seal
3. Sleeve
4. Rod end

# Cooling System Maintenance

## Cooling System Safety

- Swallowing engine coolant can cause poisoning; keep out of reach from children and pets.
- Discharge of hot, pressurized coolant or touching a hot radiator and surrounding parts can cause severe burns.
  - Always allow the engine to cool at least 15 minutes before removing the radiator cap.
  - Use a rag when opening the radiator cap, and open the cap slowly to allow steam to escape.



**Figure 56**

1. Rear screen latch      2. Rear screen


## Removing Debris from the Cooling System

**Service Interval:** Before each use or daily  
Every 100 hours  
Every 2 years

**Note:** To prevent the engine from overheating, the radiator and oil cooler must be kept clean. Normally, check daily and, if necessary, clean any debris off these parts. However, it is necessary to check and clean more frequently in extremely dusty and dirty conditions.

1. Turn the engine off and remove the key from the ignition switch.
2. Thoroughly clean all debris out of the engine area.
3. Unlatch the clamp and pivot open the rear screen (Figure 56).

4. Clean the screen thoroughly with compressed air.
5. Pivot the latches inward to release the oil cooler (Figure 57).



**Figure 57**

1. Oil cooler      2. Oil cooler latches

6. Thoroughly clean both sides of the oil cooler and the radiator (Figure 58) with compressed air.

# Belt Maintenance


## Tensioning the Alternator Belt

**Service Interval:** After the first 8 hours

Every 100 hours

1. Open the hood.
2. Check the tension of the alternator belt by pressing it (Figure 59) midway between the alternator and the crankshaft pulleys with 10 kg (22 lb) of force.


**Note:** The belt should deflect 11 mm (7/16 inch). If the deflection is incorrect, proceed to step 3. If correct, continue operation.



**Figure 58**

g004137

1. Radiator
- 
7. Pivot the oil cooler back into position and secure the latches.
  8. Close the screen and secure the latch.



**Figure 59**

g003976

1. Brace
2. Alternator belt
3. Pivot bolt

3. Loosen the bolt securing the brace to the engine (Figure 59), the bolt securing the alternator to the brace and the pivot bolt.
4. Insert a pry bar between the alternator and the engine and pry out on the alternator.
5. When you achieve the proper tension, tighten the alternator, brace, and pivot bolts to secure the adjustment.

# Controls System Maintenance

## Checking the Forward/Reverse Travel Pedal Action

With the engine shut off, operate the forward and reverse travel pedals through the full range of articulation and ensure that the mechanism returns freely to the NEUTRAL position.

## Checking the Operator-Presence-Seat Switch

**Service Interval:** Before each use or daily

1. Sit on the operator seat and start the engine.
2. Lower the cutting units to the ground.
3. Engage the cutter drive.
4. Rise from the operator seat and check that the flail rotors come to a stop after an initial 0.5 to 1 second delay.

## Checking the Cutter-Drive-Interlock Switch

1. Shut off the engine.
2. Turn the cutter-drive switch to the OFF position and turn the ignition key to position I. The cutting units drive switch indicator light should not illuminate.
3. Turn the switch to the on position. The indicator light should illuminate and the engine should not start when the ignition key is turned.

## Checking the Parking-Brake-Interlock Switch

1. Shut off the engine.
2. Engage the parking brake.
3. Turn the ignition key to position I. The parking brake indicator light should illuminate.
4. Disengage the parking brake. The indicator light should go out and the engine should not start when the ignition key is turned.
5. Set the parking brake, sit on the operator seat, and start the engine.
6. Release the parking brake.
7. Rise from the operator seat and check that the engine shuts off.

## Checking the Transmission-Neutral-Interlock Switch

1. Shut off the engine.
2. Remove your foot from the forward/reverse travel pedals.
3. Turn the ignition key to position I and the transmission neutral indicator light should illuminate.
4. Apply light pressure to the travel pedals in a forward and reverse direction to check that the indicator light turns off.

**Note:** Take extreme care to ensure that the area around the mower is clear before checking to see if the engine starts under this condition.

# Hydraulic System Maintenance

## Hydraulic System Safety

- Seek immediate medical attention if fluid is injected into skin. Injected fluid must be surgically removed within a few hours by a doctor.
- Ensure that all hydraulic-fluid hoses and lines are in good condition and all hydraulic connections and fittings are tight before applying pressure to the hydraulic system.
- Keep your body and hands away from pinhole leaks or nozzles that eject high-pressure hydraulic fluid.
- Use cardboard or paper to find hydraulic leaks.
- Safely relieve all pressure in the hydraulic system before performing any work on the hydraulic system.

## Checking the Hydraulic Lines and Hoses

**Service Interval:** Before each use or daily

Check the hydraulic lines and hoses for leaks, kinked lines, loose mounting supports, wear, loose fittings, weather deterioration, and chemical deterioration. Make all necessary repairs before operating.

## Checking the Hydraulic Fluid

**Service Interval:** Before each use or daily

The reservoir is filled at the factory with approximately 32 L (8.5 US gallons) of high-quality hydraulic fluid. The best time to check the hydraulic fluid is when it is cold.

The recommended replacement fluid is:

### **Toro Premium All Season Hydraulic Fluid:**

Available in 19 L (5 US gallon) containers or 208 L (55 US gallon) drums—contact your authorized Toro distributor for part numbers.

**Alternative fluids:** If the Toro fluid is not available, other fluids may be used provided that they meet all of the following material properties and industry specifications. Check with your oil supplier to identify a satisfactory product.

**Note:** Toro does not assume responsibility for damage caused by improper substitutions, so use

only products from reputable manufacturers who stand behind their recommendation.

### **High Viscosity Index/Low Pour Point Antiwear Hydraulic Fluid, ISO VG 46 Multigrade**

Material Properties:

|                             |                                                                     |
|-----------------------------|---------------------------------------------------------------------|
| Viscosity, ASTM D445        | cSt @ 40°C (104°F)<br>44 to 48<br>cSt @ 100°C (212°F)<br>7.9 to 9.1 |
| Viscosity index, ASTM D2270 | 140 or higher (high viscosity index indicates a multiweight fluid)  |
| Pour point, ASTM D97        | -36.7°C to -45°C (-34°F to -49°F)                                   |
| FZG, fail stage             | 11 or better                                                        |
| Water content (new fluid)   | 500 ppm (maximum)                                                   |

Industry Specifications:

Vickers I-286-S, Vickers M-2950-S, Denison HF-0, Vickers 35 VQ 25 (Eaton ATS373-C)

The proper hydraulic fluids must be specified for mobile machinery (as opposed to industrial plant usage), multiweight-type, with ZnDTP or ZDDP antiwear additive package (not an ashless-type fluid).

**Important:** Many hydraulic fluids are almost colorless, making it difficult to spot leaks. A red dye additive for the hydraulic system oil is available in 20 ml (2/3 fl oz) bottles. One bottle is sufficient for 15 to 22 L (4 to 6 US gallons) of hydraulic fluid. Order part 44-2500 from your authorized Toro distributor.


**Synthetic, Biodegradable Hydraulic Fluid:** Available in 19 L (5 US gallon) containers or 208 L (55 US gallon) drums—contact your authorized Toro distributor for part numbers.

This high-quality, synthetic, biodegradable fluid has been tested and found compatible for this Toro model. Other brands of synthetic fluid may have seal compatibility problems and Toro cannot assume responsibility for unauthorized substitutions.

**Note:** This synthetic fluid is not compatible with the Toro Biodegradable Fluid previously sold. See your Toro Distributor for more information.

Alternative fluids:

- Mobil EAL EnviroSyn H 46 (US)
  - Mobil EAL Hydraulic Oil 46 (international)
1. Park the machine on a level surface, lower the cutting units, engage the parking brake, shut off the engine, and remove the key.
  2. Check the sight-level gauge on the side of the tank.  
**Note:** The level needs to be at the upper mark.
  3. If additional hydraulic fluid is needed, clean the area around the filler neck and the cap of the hydraulic tank ([Figure 60](#)) and remove the cap.



G014570

g014570

**Figure 60**

1. Hydraulic-tank cap
2. Fluid tank
3. Sight-level gauge

4. Remove the cap and fill the tank to the upper mark on the sight-level gauge.

**Important:** Do not overfill the tank.

5. Install the cap onto the tank.


## Servicing the Hydraulic System

**Service Interval:** Every 500 hours

**Note:** Keep water away from electrical components. Use a dry cloth or brush to clean such areas.

This procedure is best carried out when the hydraulic fluid is warm (not hot). Lower the cutting units to the ground and drain the hydraulic system.

1. Remove the hydraulic tank drain plug and let the oil flow into the drain pan.
2. When the oil stops, install the drain plug with a new seal.
3. Remove the oil tank suction flange to gain access to the suction strainer.
4. Unscrew and remove the strainer and clean with paraffin or petrol before installing.
5. Install the return line oil filter element.
6. Install the transmission oil filter element.
7. Fill the hydraulic tank with fresh, clean hydraulic fluid of the recommended grade.
8. Run the machine and operate all hydraulic systems until the hydraulic fluid is warm.
9. Check the fluid level and top up as necessary to the upper mark on the sight-level gauge.



G014452


g014452

**Figure 61**

1. Oil-tank filler cap
2. Suction strainer
3. Filler strainer

## Checking the Hydraulic-Fluid-Overheat Warning System

**Service Interval:** Every 500 hours



g022285

g022285

**Figure 62**

1. Temperature switch
2. Hydraulic-fluid tank

1. Turn the ignition key to the ignition on position I.
2. Disconnect the red/yellow wire terminal from the hydraulic-tank-temperature switch.
3. Touch the metal terminal of the wire onto a suitable earth point, ensuring that the metal surfaces make good contact.

The horn sounds and the hydraulic-fluid-temperature-warning light illuminates to confirm correct operation. If necessary, make repairs before operating the mower.

# Cutting Unit Maintenance

## Blade Safety

- Inspect the blade periodically for wear or damage.
- Use care when checking the blades. Wrap the blades or wear gloves, and use caution when servicing the blades. Only replace or sharpen the blades; never straighten or weld them.
- On multi-bladed machines, take care as rotating 1 blade can cause other blades to rotate.


## Replacing the Blades

**Service Interval:** Yearly—Replace the blades.

To maintain balance, replace blades only as an opposed pair or a whole rotor at a time. Also replace the bushing, the bolt, and the locknut when you replace a blade. There are 2 service kits available for blade replacement; refer to the *Parts Catalog*.

1. Raise the cutting units and secure them with the transport latches.
2. Engage the parking brake, shut off the engine, and remove the key.
3. If you are replacing blades on the center cutting unit, remove the entire cutting unit unless an overhead lift is available.
4. Turn the rotor slowly by hand so that each row of flails are in the desired position and you can easily access them.
5. Use the rotor locking tool (provided in the blade-sharpening kit) to lock the rotor.
6. Remove any debris from the bolt head and the nut and clean the protruding threads with a wire brush.
7. Mark the position of the bolt head so that you can replace the bolts from the same side.
8. Holding the blade in a rag or padded glove, remove the nut, bolt, bushing, and blade ([Figure 63](#)).

**Note:** If needed, apply penetrating oil to the threads to make the nut easier to remove.



**Figure 63**

- |         |            |
|---------|------------|
| 1. Nut  | 3. Bushing |
| 2. Bolt | 4. Blade   |

9. Discard the blade, bushing, nut, and bolt.
10. Install a new blade and bushing with a new nut and blade bolt ([Figure 63](#)).

**Note:** Pay attention to the bolt-head-position markings so that you replace the bolt in the same direction.

11. Torque the fasteners to 45 N·m (33 ft-lb).

## Checking the Blade Bolts

**Service Interval:** Every 50 hours

Make sure that all blade bolts are torqued to 45 N·m (33 ft-lb).


## Inspecting the Blades

**Service Interval:** Every 50 hours—Inspect the blades for damage and excessive wear.

Every 50 hours—Make sure that each blade bolt is torqued to 45 N·m (33.2 ft-lb).

**Important:** Blades should always be replaced at the same time as the opposite blade/as pairs to maintain balance.


1. Park the machine on a level surface.
2. Raise and support the cutting unit with the transport latches.
3. Shut off the engine, engage the parking brake, and remove the key.
4. Inspect each blade for damage paying particular attention to the fasteners, cutting edge, and installation hole (Figure 64). Replace all damaged blades and fasteners.



**Figure 64**

1. Cutting edge
2. Installation hole

5. Inspect each blade for excessive wear using the wear line (Figure 65). When a blade is worn down to the wear line, replace the blade.



**Figure 65**

1. Wear line

6. Make sure that each blade bolt is torqued to 45 N·m (33.2 ft-lb).
7. Grip each blade and make sure that there is not more than a total of 3 mm (1/8 inch) of free movement in either direction from the rotor. If there is more than a total of 3 mm (1/8 inch) of free movement, replace the blade.
8. Check each pair of opposite blades for a weight difference between them.

**Note:** Each pair of opposite blades should not have a weight difference of more than 10 grams.

## **⚠ DANGER**


**A worn or damaged blade can break, and a piece of the blade could be thrown toward you or bystanders, resulting in serious personal injury or death.**

- Inspect the blades periodically for wear or damage.
- Replace a worn or damaged blade.

## **Checking the Rear Guard**

**Service Interval:** Before each use or daily

Inspect the rear guard for wear or damage (Figure 66). Replace the rear guard if it is damaged to prevent objects being thrown into the operator's area.



**Figure 66**

1. Rear guard

## **Clearing a Blocked Rotor**

### **⚠ WARNING**

**Residual pressure in the hydraulic system could cause injury through sudden movement of the flail rotor(s) when the blockage is released.**

- Never attempt to rotate or clear blockage from the flail rotors by hand.
- Always wear protective gloves and use a wooden pole.
- Ensure that the wooden pole will fit in the flail rotor and is long enough to provide sufficient leverage to release the blockage.

1. Set the cutting-unit-drive switch to the OFF position.
2. Park the machine on level ground, release the forward or reverse travel pedals, set the throttle control to the slow engine-speed position, and engage the parking brake.
3. Lower the cutting units to the ground or securely lock them in the designated transport position.
4. Shut off the engine, remove the ignition key, and wait for the flail rotors to stop moving.
5. Use a wooden pole to remove the blockage.

**Important:** The flail rotor may rotate when you release the blockage.

**Important:** Support the wooden pole in the cutting unit to avoid using excessive force when you remove the blockage.

6. Remove the wooden pole from the cutting unit before you start the engine.
7. Repair or adjust the cutting unit if necessary.

## Checking the Rubber Guard

**Service Interval:** Before each use or daily

Inspect the rubber guard for wear or damage (Figure 67). Replace the rubber guard if it is damaged to prevent objects being thrown toward you.




Figure 67

1. Rubber guard

## Checking the Cutting Unit Pivot

**Service Interval:** Before each use or daily

Every 50 hours

1. Raise and support the cutting unit.
2. Grip each cutting unit and check for excessive play from side to side or up and down.

## Checking the Rotor

**Service Interval:** Before each use or daily—Check for any unusual vibration of the rotor.

Every 50 hours—Check for excessive play in the rotor bearings.

To check for any unusual vibration of the rotor, run each cutting unit in turn at full engine speed.

**Note:** If any there is unusual vibration, check for damage or excessive wear of the rotor or blades. All blades need to have a similar level of wear as their weight affects the balance of the rotor.

**Note:** If you cannot resolve the vibration issue, contact your authorized Toro distributor.

1. Raise and support the cutting unit.
2. Grip the rotor at each end and check for excessive end play.

**Note:** If you detect the rotor has excessive end play, contact your authorized Toro distributor.

**Note:** If the rotor needs to be replaced or balanced, contact your authorized Toro distributor.

## Checking the Rear-Roller Bearing Adjustment


**Service Interval:** Every 50 hours

**Important:** Keep the roller bearings on the cutting units in good adjustment to ensure maximum working life. Excessive roller-end play causes premature bearing damage.

1. Grip the roller and move from side to side and up and down.
2. If there is excessive movement, carefully tighten the nuts at each end of the roller with the wrench just enough to remove any end play (Figure 68).

**Note:** The roller should still rotate freely after adjustment. Overtightening the nuts could lead to premature bearing damage.

**Note:** Adjust the nuts by an equal amount at both ends of the roller.



**Figure 68**


1. Nut

## Checking the Rear-Roller Scraper Wire Tension

**Service Interval:** Every 50 hours

Ensure that the scraper wires are correctly tensioned for maximum working life.

1. Carefully tighten the scraper wire retaining nuts to remove any slack from the scraper wires.
2. Tighten the nuts 4 full turns to correctly tension the wire (Figure 69).



**Figure 69**

1. Scraper wire retaining nuts

**Note:** Do not overtighten the scraper wires.

## Cleaning

### Washing the Machine

Wash the machine as needed using water alone or with a mild detergent. You may use a rag when washing the machine.

**Important:** Do not use brackish or reclaimed water to clean the machine.

**Important:** Do not use power-washing equipment to wash the machine. Power-washing equipment may damage the electrical system, loosen important decals, or wash away necessary grease at friction points. Avoid excessive use of water near the control panel, engine, and battery.

**Important:** Do not wash the machine with the engine running. Washing the machine with the engine running may result in internal engine damage.

# Storage

## Storage Safety

- Shut off the engine, remove the key, and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
  - Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.
5. Shut off the engine and remove the key.
  6. Flush the fuel tank with fresh, clean fuel.
  7. Secure all of the fuel-system fittings.
  8. Thoroughly clean and service the air-cleaner assembly.
  9. Seal the air-cleaner inlet and the exhaust outlet with weatherproof tape.
  10. Check the antifreeze protection and add a 50/50 solution of water and ethylene glycol antifreeze as needed for the expected minimum temperature in your area.

## Preparing the Traction Unit

1. Park the machine on a level surface, lower the cutting units, engage the parking brake, shut off the engine, and remove the key.
2. Thoroughly clean the traction unit, cutting units, and the engine.
3. Check the tire pressure; refer to [Checking the Tire Pressure \(page 42\)](#).
4. Check all fasteners for looseness; tighten them as necessary.
5. Grease or oil all grease fittings and pivot points. Wipe up any excess lubricant.
6. Lightly sand and use touch-up paint on painted areas that are scratched, chipped, or rusted. Repair any dents in the metal body.
7. Service the battery and cables as follows; refer to [Electrical System Safety \(page 41\)](#):
  - A. Remove the battery terminals from the battery posts.
  - B. Clean the battery, terminals, and posts with a wire brush and baking-soda solution.
  - C. Coat the cable terminals and battery posts with Grafo 112X skin-over grease (Toro Part No. 505-47) or petroleum jelly to prevent corrosion.
  - D. Slowly charge the battery every 60 days for 24 hours to prevent lead sulfation of the battery.

## Preparing the Engine

1. Drain the engine oil from the oil pan and install the drain plug.
2. Remove and discard the oil filter. Install a new oil filter.
3. Fill the engine with specified motor oil.
4. Start the engine and run it at idle speed for approximately 2 minutes.

# Troubleshooting

| Problem                                                                                                          | Possible Cause                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Corrective Action                                                                                                                                                                                                                                                                                                                    |
|------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| There are areas of uncut grass at the overlap between flail rotors.                                              | <ol style="list-style-type: none"> <li>1. You are turning too tightly.</li> <li>2. The machine slides sideways when travelling across the face of a slope.</li> <li>3. There is no ground contact on an end of the cutting unit because of poorly routed hoses or incorrectly positioned hydraulic adaptors.</li> <li>4. There is no ground contact on an end of the cutting unit because a pivot pin is seizing.</li> <li>5. There is no ground contact on an end of the cutting unit because of grass buildup under the cutting unit.</li> </ol>                           | <ol style="list-style-type: none"> <li>1. Increase the turning radius</li> <li>2. Mow up/down the slope.</li> <li>3. Correct the hose routing or the position of the hydraulic adaptors.</li> <li>4. Release and grease the pivot points.</li> <li>5. Clear the grass buildup.</li> </ol>                                            |
| There are full-width ridge lines in the cut across the direction of travel.                                      | <ol style="list-style-type: none"> <li>1. The forward speed is too high.</li> <li>2. The flail rotor speed is too slow.</li> <li>3. The height of cut is too low.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                 | <ol style="list-style-type: none"> <li>1. Reduce forward speed.</li> <li>2. Increase the mower engine speed.</li> <li>3. Raise the height of cut.</li> </ol>                                                                                                                                                                         |
| There are ridge lines in the cut grass, across the direction of travel, over the cutting width of a flail rotor. | <ol style="list-style-type: none"> <li>1. A flail rotor is running slow.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | <ol style="list-style-type: none"> <li>1. Check the flail rotor speed; contact your distributor.</li> </ol>                                                                                                                                                                                                                          |
| There is a step in the cut grass height at the point of overlap between flail rotors.                            | <ol style="list-style-type: none"> <li>1. There is an inconsistent height-of-cut setting on a flail rotor.</li> <li>2. The raise/lower position control is not in the float position.</li> <li>3. There is no ground contact on an end of the cutting unit because of poorly routed hoses or incorrectly positioned hydraulic adaptors.</li> <li>4. There is no ground contact on an end of the cutting unit because of pivot pins seizing.</li> <li>5. There is no ground contact on an end of the cutting unit because of grass buildup under the cutting unit.</li> </ol> | <ol style="list-style-type: none"> <li>1. Check and adjust the height-of-cut setting.</li> <li>2. Set the position control to the float position.</li> <li>3. Correct the hose routing and the position of the hydraulic adaptors.</li> <li>4. Release and grease the pivot points.</li> <li>5. Remove the grass buildup.</li> </ol> |
| There are some uncut or poorly cut strands of grass.                                                             | <ol style="list-style-type: none"> <li>1. The height of cut is too high.</li> <li>2. The cutting edges of the flails are rounded.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                                                 | <ol style="list-style-type: none"> <li>1. Lower the height-of-cut setting.</li> <li>2. Sharpen the blades.</li> </ol>                                                                                                                                                                                                                |
| There are lines of uncut or badly cut grass in the direction of travel.                                          | <ol style="list-style-type: none"> <li>1. The cutting units are bouncing.</li> <li>2. There are worn flail bearings/bearing housing pivots.</li> <li>3. There are loose components in the cutting unit.</li> <li>4. Flail blades are not pivoting freely.</li> </ol>                                                                                                                                                                                                                                                                                                         | <ol style="list-style-type: none"> <li>1. Reduce the forward speed and reduce the weight transfer.</li> <li>2. Replace any worn parts.</li> <li>3. Check and tighten components as necessary.</li> <li>4. Ensure that all flail blades are able to pivot freely.</li> </ol>                                                          |
| There is scalping of the turf.                                                                                   | <ol style="list-style-type: none"> <li>1. The undulations are too severe for the height-of-cut setting.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                                                                           | <ol style="list-style-type: none"> <li>1. Raise the height of cut.</li> </ol>                                                                                                                                                                                                                                                        |

| Problem                                             | Possible Cause                                                                                                                                                                                                                                                                                                                                                                                                            | Corrective Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The engine does not start with the ignition key.    | <ol style="list-style-type: none"> <li>1. The transmission-neutral-interlock switch is not energized.</li> <li>2. The parking-brake-interlock switch is not energized.</li> <li>3. The cutting-unit-drive-interlock switch is not energized.</li> <li>4. There is a malfunctioning electrical connection.</li> </ol>                                                                                                      | <ol style="list-style-type: none"> <li>1. Remove your foot from the forward/reverse pedals or check the setting of the transmission-neutral-interlock switch.</li> <li>2. Move the parking-brake switch to the ON position.</li> <li>3. Move the cutting unit switch to the OFF position.</li> <li>4. Locate and correct the fault in the Electrical System.</li> </ol>                                                                                                                                       |
| The battery has no power.                           | <ol style="list-style-type: none"> <li>1. A terminal connection is loose or corroded.</li> <li>2. The alternator belt is loose or worn.</li> <li>3. The battery is discharged.</li> <li>4. There is an electrical short circuit.</li> </ol>                                                                                                                                                                               | <ol style="list-style-type: none"> <li>1. Clean and tighten the terminal connections. Charge the battery.</li> <li>2. Adjust the tension or replace the belt; refer to engine operator's manual.</li> <li>3. Charge or replace the battery.</li> <li>4. Locate the short circuit and fix it.</li> </ol>                                                                                                                                                                                                       |
| The hydraulic oil system is overheating.            | <ol style="list-style-type: none"> <li>1. There is a blocked screen.</li> <li>2. The oil cooler fins are dirty/blocked.</li> <li>3. The engine radiator is dirty/blocked.</li> <li>4. The relief valve setting is low.</li> <li>5. The oil level is low.</li> <li>6. The brakes are engaged.</li> <li>7. There is a malfunctioning fan or fan drive.</li> </ol>                                                           | <ol style="list-style-type: none"> <li>1. Clean the screen.</li> <li>2. Clean the fins.</li> <li>3. Clean the radiator.</li> <li>4. Have the relief valve pressure checked. Consult your authorized distributor.</li> <li>5. Fill the reservoir to the correct level.</li> <li>6. Disengage the brakes.</li> <li>7. Check the fan operation and service it as required.</li> </ol>                                                                                                                            |
| The brake system does not operate correctly.        | <ol style="list-style-type: none"> <li>1. There is a malfunctioning wheel motor brake assembly.</li> <li>2. The brake discs are worn.</li> <li>3. Insufficient brake release pressure.</li> </ol>                                                                                                                                                                                                                         | <ol style="list-style-type: none"> <li>1. Consult your authorized distributor.</li> <li>2. Replace the brake discs; consult your authorized distributor.</li> <li>3. Raise the engine revs; consult your authorized distributor.</li> </ol>                                                                                                                                                                                                                                                                   |
| There is a lack of steering.                        | <ol style="list-style-type: none"> <li>1. The steering valve is malfunctioning.</li> <li>2. A hydraulic cylinder is malfunctioning.</li> <li>3. A steering hose is damaged.</li> </ol>                                                                                                                                                                                                                                    | <ol style="list-style-type: none"> <li>1. Service or replace the steering valve.</li> <li>2. Service or replace the hydraulic cylinder.</li> <li>3. Replace the hose.</li> </ol>                                                                                                                                                                                                                                                                                                                              |
| There is no machine movement in forward or reverse. | <ol style="list-style-type: none"> <li>1. The parking brake is engaged.</li> <li>2. The oil level is low.</li> <li>3. The reservoir has the wrong kind of oil.</li> <li>4. The drive pedal linkage is damaged.</li> <li>5. The transmission pump is damaged.</li> <li>6. The transmission bypass valve is open.</li> <li>7. There is a broken drive coupling.</li> <li>8. Insufficient brake release pressure.</li> </ol> | <ol style="list-style-type: none"> <li>1. Release the parking brake.</li> <li>2. Fill the reservoir to the correct level.</li> <li>3. Drain the reservoir and fill it with the correct oil.</li> <li>4. Check the linkage and replace any damaged or worn parts.</li> <li>5. Have the transmission pump overhauled by your authorized distributor.</li> <li>6. Close the bypass valve.</li> <li>7. Replace the drive coupling.</li> <li>8. Raise engine revs; consult your authorized distributor.</li> </ol> |
| The machine creeps forward or backward in neutral.  | <ol style="list-style-type: none"> <li>1. The transmission neutral adjustment is set incorrectly.</li> </ol>                                                                                                                                                                                                                                                                                                              | <ol style="list-style-type: none"> <li>1. Adjust the transmission neutral linkage setting.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                         |

| <b>Problem</b>                                                              | <b>Possible Cause</b>                                                                                                                                                                                                                                                                                                                                                                            | <b>Corrective Action</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-----------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| There is excessive noise in the hydraulic system.                           | <ol style="list-style-type: none"> <li>1. A pump is malfunctioning.</li> <li>2. A motor is malfunctioning.</li> <li>3. Air is leaking into the system.</li> <li>4. A suction strainer is blocked or damaged.</li> <li>5. The oil has excessive viscosity due to cold conditions.</li> <li>6. The relief valve setting is low.</li> <li>7. The hydraulic-fluid level is low.</li> </ol>           | <ol style="list-style-type: none"> <li>1. Identify the noisy pump and service or replace it.</li> <li>2. Identify the noisy motor and service or replace it.</li> <li>3. Tighten or replace the hydraulic fittings, particularly in the suction lines.</li> <li>4. Clean and replace the suction strainer or renew it as necessary.</li> <li>5. Allow the system to warm up.</li> <li>6. Have the relief valve pressure checked. Consult your authorized distributor.</li> <li>7. Fill the hydraulic-fluid reservoir to the correct level.</li> </ol>                                  |
| After an initial period of satisfactory operation, the machine loses power. | <ol style="list-style-type: none"> <li>1. A pump or motor is worn.</li> <li>2. The hydraulic-fluid level is low.</li> <li>3. The oil in the hydraulic system has the wrong viscosity.</li> <li>4. The oil-filter element is blocked.</li> <li>5. The pressure relief valve is malfunctioning.</li> <li>6. The system is overheating.</li> <li>7. There are leaks on the suction hose.</li> </ol> | <ol style="list-style-type: none"> <li>1. Replace parts as necessary.</li> <li>2. Fill hydraulicfluid tank to correct level.</li> <li>3. Replace the oil in the hydraulic tank with the correct viscosity-grade oil; refer to the Specifications section.</li> <li>4. Change the filter element.</li> <li>5. Have the relief valve cleaned and pressure checked. Consult your authorized distributor.</li> <li>6. Reduce the work rate (increase the height of cut or reduce the forward speed).</li> <li>7. Check and tighten the fittings. Replace the hose if necessary.</li> </ol> |
| A flail rotor 'knocks' while rotating.                                      | <ol style="list-style-type: none"> <li>1. The flail-rotor bearings are worn.</li> </ol>                                                                                                                                                                                                                                                                                                          | <ol style="list-style-type: none"> <li>1. Replace the bearings as necessary.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| One flail rotor rotates slowly.                                             | <ol style="list-style-type: none"> <li>1. A flail-rotor bearing is seized.</li> <li>2. A motor with incorrect rotation was installed.</li> <li>3. The motor integral valves are not working correctly.</li> <li>4. The motor is worn.</li> </ol>                                                                                                                                                 | <ol style="list-style-type: none"> <li>1. Replace the bearings as necessary.</li> <li>2. Check the motor and replace it if necessary.</li> <li>3. Have the valves cleaned and checked.</li> <li>4. Replace the motor.</li> </ol>                                                                                                                                                                                                                                                                                                                                                       |
| A cutting unit fails to lift out of work.                                   | <ol style="list-style-type: none"> <li>1. There is a lift cylinder seal failure.</li> <li>2. The pressure relief valve is jammed open or set wrong.</li> <li>3. There is a malfunctioning control valve.</li> <li>4. There is mechanical blockage.</li> </ol>                                                                                                                                    | <ol style="list-style-type: none"> <li>1. Replace the seals.</li> <li>2. Have the relief valve pressure checked. Consult your authorized distributor.</li> <li>3. Overhaul the control valve.</li> <li>4. Remove the blockage.</li> </ol>                                                                                                                                                                                                                                                                                                                                              |
| The cutting units do not follow the contours of the ground.                 | <ol style="list-style-type: none"> <li>1. The hose routing or the orientation of the hydraulic fittings is incorrect.</li> <li>2. The pivot points are too tight.</li> <li>3. The mower is being operated in the 'hold' position.</li> <li>4. The weight transfer is set too high.</li> </ol>                                                                                                    | <ol style="list-style-type: none"> <li>1. Move the cutting units throughout the extremes of movement and observe any tightness in the hoses. Correctly route the hoses and orientate the fittings as necessary.</li> <li>2. Release and grease the pivot point as necessary.</li> <li>3. Move the position-control switch to 'down / float' position.</li> <li>4. Reduce the weight transfer.</li> </ol>                                                                                                                                                                               |

| <b>Problem</b>                                             | <b>Possible Cause</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | <b>Corrective Action</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The cutting units fail to start-up when lowered into work. | <ol style="list-style-type: none"> <li>1. The seat-sensor switch is malfunctioning.</li> <li>2. The hydraulic-fluid level is low.</li> <li>3. A driveshaft is sheared.</li> <li>4. The pressure relief valve is jammed open or set wrong.</li> <li>5. A flail rotor is jammed.</li> <li>6. A cutting unit control valve is in the 'off' position, caused by malfunctioning control valve.</li> <li>7. A cutting unit control valve is in the 'off' position, caused by an electrical fault.</li> <li>8. The lift-arm-proximity switch is incorrectly set.</li> </ol> | <ol style="list-style-type: none"> <li>1. Check the mechanical and electrical operation of the switch and ensure the operator weight has been set correctly.</li> <li>2. Fill the hydraulic-fluid reservoir to the correct level.</li> <li>3. Check the motor and flail rotor driveshafts and replace them if necessary.</li> <li>4. Have the relief valve pressure checked. Consult your authorized dealer.</li> <li>5. Clear any jams as necessary.</li> <li>6. Overhaul the control valve.</li> <li>7. Have the electrical system checked for an electrical fault.</li> <li>8. Check and adjust the proximity switch.</li> </ol> |
| The flail rotors rotate in the wrong direction.            | <ol style="list-style-type: none"> <li>1. The hoses are connected wrong.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | <ol style="list-style-type: none"> <li>1. Check the hydraulic circuit and connect the hoses correctly.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

**Notes:**

## EEA/UK Privacy Notice

### **Toro's Use of Your Personal Information**

The Toro Company ("Toro") respects your privacy. When you purchase our products, we may collect certain personal information about you, either directly from you or through your local Toro company or dealer. Toro uses this information to fulfil contractual obligations - such as to register your warranty, process your warranty claim or to contact you in the event of a product recall - and for legitimate business purposes - such as to gauge customer satisfaction, improve our products or provide you with product information which may be of interest. Toro may share your information with our subsidiaries, affiliates, dealers or other business partners in connection these activities. We may also disclose personal information when required by law or in connection with the sale, purchase or merger of a business. We will never sell your personal information to any other company for marketing purposes.

### **Retention of your Personal Information**

Toro will keep your personal information as long as it is relevant for the above purposes and in accordance with legal requirements. For more information about applicable retention periods please contact [legal@toro.com](mailto:legal@toro.com).

### **Toro's Commitment to Security**

Your personal information may be processed in the US or another country which may have less strict data protection laws than your country of residence. Whenever we transfer your information outside of your country of residence, we will take legally required steps to ensure that appropriate safeguards are in place to protect your information and to make sure it is treated securely.

### **Access and Correction**

You may have the right to correct or review your personal data, or object to or restrict the processing of your data. To do so, please contact us by email at [legal@toro.com](mailto:legal@toro.com). If you have concerns about the way in which Toro has handled your information, we encourage you to raise this directly with us. Please note that European residents have the right to complain to your Data Protection Authority.



## The Toro Warranty

Two-Year or 1,500 Hours Limited Warranty

### Conditions and Products Covered

The Toro Company and its affiliate, Toro Warranty Company, pursuant to an agreement between them, jointly warrant your Toro Commercial product ("Product") to be free from defects in materials or workmanship for 2 years or 1,500 operational hours\*, whichever occurs first. This warranty is applicable to all products with the exception of Aerators (refer to separate warranty statements for these products). Where a warrantable condition exists, we will repair the Product at no cost to you including diagnostics, labor, parts, and transportation. This warranty begins on the date the Product is delivered to the original retail purchaser.

\* Product equipped with an hour meter.

### Instructions for Obtaining Warranty Service

You are responsible for notifying the Commercial Products Distributor or Authorized Commercial Products Dealer from whom you purchased the Product as soon as you believe a warrantable condition exists. If you need help locating a Commercial Products Distributor or Authorized Dealer, or if you have questions regarding your warranty rights or responsibilities, you may contact us at:

Toro Commercial Products Service Department  
Toro Warranty Company  
8111 Lyndale Avenue South  
Bloomington, MN 55420-1196  
  
952-888-8801 or 800-952-2740  
E-mail: commercial.warranty@toro.com

### Owner Responsibilities

As the product owner, you are responsible for required maintenance and adjustments stated in your *Operator's Manual*. Repairs for product issues caused by failure to perform required maintenance and adjustments are not covered under this warranty.

### Items and Conditions Not Covered

Not all product failures or malfunctions that occur during the warranty period are defects in materials or workmanship. This warranty does not cover the following:

- Product failures which result from the use of non-Toro replacement parts, or from installation and use of add-on, or modified non-Toro branded accessories and products.
- Product failures which result from failure to perform recommended maintenance and/or adjustments.
- Product failures which result from operating the Product in an abusive, negligent, or reckless manner.
- Parts consumed through use that are not defective. Examples of parts which are consumed, or used up, during normal Product operation include, but are not limited to, brake pads and linings, clutch linings, blades, reels, rollers and bearings (sealed or greasable), bed knives, spark plugs, castor wheels and bearings, tires, filters, belts, and certain sprayer components such as diaphragms, nozzles, and check valves.
- Failures caused by outside influence, including, but not limited to, weather, storage practices, contamination, use of unapproved fuels, coolants, lubricants, additives, fertilizers, water, or chemicals.
- Failure or performance issues due to the use of fuels (e.g. gasoline, diesel, or biodiesel) that do not conform to their respective industry standards.
- Normal noise, vibration, wear and tear, and deterioration. Normal "wear and tear" includes, but is not limited to, damage to seats due to wear or abrasion, worn painted surfaces, scratched decals or windows.

### Countries Other than the United States or Canada

Customers who have purchased Toro products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact your Authorized Toro Service Center.

### Parts

Parts scheduled for replacement as required maintenance are warranted for the period of time up to the scheduled replacement time for that part. Parts replaced under this warranty are covered for the duration of the original product warranty and become the property of Toro. Toro will make the final decision whether to repair any existing part or assembly or replace it. Toro may use remanufactured parts for warranty repairs.

### Deep Cycle and Lithium-Ion Battery Warranty

Deep cycle and Lithium-Ion batteries have a specified total number of kilowatt-hours they can deliver during their lifetime. Operating, recharging, and maintenance techniques can extend or reduce total battery life. As the batteries in this product are consumed, the amount of useful work between charging intervals will slowly decrease until the battery is completely worn out. Replacement of worn out batteries, due to normal consumption, is the responsibility of the product owner. Note: (Lithium-Ion battery only): Pro-rated after 2 years. Refer to the battery warranty for additional information.

### Lifetime Crankshaft Warranty (ProStripe 02657 Model Only)

The ProStripe which is fitted with a genuine Toro Friction Disc and Crank-Safe Blade Brake Clutch (integrated Blade Brake Clutch (BBC) + Friction Disc assembly) as original equipment and used by the original purchaser in accordance with recommended operating and maintenance procedures, are covered by a Lifetime Warranty against engine crankshaft bending. Machines fitted with friction washers, Blade Brake Clutch (BBC) units and other such devices are not covered by the Lifetime Crankshaft Warranty.

### Maintenance is at Owner's Expense

Engine tune-up, lubrication, cleaning and polishing, replacement of filters, coolant, and completing recommended maintenance are some of the normal services Toro products require that are at the owner's expense.

### General Conditions

Repair by an Authorized Toro Distributor or Dealer is your sole remedy under this warranty.

**Neither The Toro Company nor Toro Warranty Company is liable for indirect, incidental or consequential damages in connection with the use of the Toro Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. Except for the Emissions warranty referenced below, if applicable, there is no other express warranty. All implied warranties of merchantability and fitness for use are limited to the duration of this express warranty.**

Some states do not allow exclusions of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

### Note Regarding Emissions Warranty

The Emissions Control System on your Product may be covered by a separate warranty meeting requirements established by the U.S. Environmental Protection Agency (EPA) and/or the California Air Resources Board (CARB). The hour limitations set forth above do not apply to the Emissions Control System Warranty. Refer to the Engine Emission Control Warranty Statement supplied with your product or contained in the engine manufacturer's documentation.